

CARE & MAINTENANCE (Continued)

- To remove crumbs, slide out the Crumb Tray and discard crumbs. Wipe clean and replace. Crumb Tray should be emptied and cleaned after each use.
- To remove baked-on grease, soak Tray in hot, soapy water. Never operate the oven without the Crumb Tray in place.
- Never wrap the cord around the Bravo.

Storage

- Unplug the Bravo and let unit cool down completely.
- Make sure that all parts are cleaned and dry.

TROUBLESHOOTING

The Bravo was engineered with an automatic shut-off feature to prevent overheating during use. If the Bravo shuts off to cool itself down, an odor may be detected. Unplug the unit and wait for it to completely cool down. To prevent the Bravo from overheating, do not cook foods at higher temperatures or longer times than recommended.

Problem:	Possible Cause(s):	Solution(s):
The Bravo does not work.	The appliance is not plugged in. Did not press "ON/OFF" button.	Insert the plug into an appropriate grounded power socket. Press "ON/OFF". If still not working, contact Customer Service at 1-877-689-2838 or email help@nuwavenow.com .
The door to Bravo will not close completely.	Food item is too large. Oven racks or accessories are not properly set in place.	Use smaller amounts of food to cook. Make sure all racks and pans are slid into place and pushed all the way to the back of the unit.
The food is cooked unevenly.	Depending on size and amount, some foods may need to be turned or rotated throughout cooking.	Check cooking progress throughout. Turn or rotate as needed to ensure even cooking.

TROUBLESHOOTING (Continued)

Problem:	Possible Cause(s):	Solution(s):
Bake vs. Roast vs. Broil	When to use these three functions.	Use Bake when cooking items that rise (i.e., cakes and cookies). Use Roast for dense foods that are browned throughout the cooking process. Use Broil to quickly brown or crisp a food item.
The Crumb Tray will not slide back into position.	The Crumb Tray is not placed into the slot correctly. Something is blocking the Tray from sliding into position.	Remove the Crumb Tray and clean away any food items that may have accumulated in the back of the Bravo.
White smoke is coming out of the product.	You are cooking greasy foods. The Baking Pan contains greasy residue from previous uses. When preparing greasy ingredients in the unit, large amounts of oil can smoke. The oil will produce white smoke. This will not affect the final cooking effect. White smoke is caused by grease heating up on the wire racks and/or Crumb Tray.	Clean Cooking Racks and Crumb Tray regularly between use.
The LED screen is blank.	Unit overheated and has shut itself down. No action was taken after certain stages of cooking and unit shut down. Control Panel not working correctly.	Unplug the Bravo and allow the unit to completely cool. Plug back in and see if it is working. If the LED screen remains blank, contact Customer Service at 1-877-689-2838 or email help@nuwavenow.com .
The Bravo is not heating.	Unit is unplugged. Unit has overheated. Heating elements not working.	Make sure the Bravo is plugged in. Make sure the unit is completely cooled. Plug in and see if unit comes up to correct temperature. If unit continues to not heat up, contact Customer Service at 1-877-689-2838 or email help@nuwavenow.com .

TROUBLESHOOTING (Continued)

If the Bravo needs to be replaced or returned to the manufacturer, contact Customer Service at 1-877-689-2838 or email: help@nuwavenow.com

Contact Customer Service if any of these errors occur:

Code	Er1	Er2	Er3	Er4
"Prob" Error	Probe short circuit	NTC short circuit	NTC open	NTC overheated

LIMITED WARRANTY

The Bravo XL Smart Oven

THE MANUFACTURER WARRANTS

The Bravo, including the Power Base, Heavy-Duty Cooking Racks, Enamel Baking Pan, Enamel Broiler Rack, Chrome-Plated Air Fry Basket, Pull-Out Crumb Tray, Temperature Probe, and all electrical components are warranted for 3 years from the date of purchase, under normal household use, and when operated in accordance with the Manufacturer's written instructions.

The Manufacturer will provide the necessary parts and labor to repair any part of the Bravo at the NuWave, LLC Service Department. After the expiration of the warranty, the cost of the labor and parts will be the responsibility of the owner.

THE WARRANTY DOES NOT COVER

The Limited Warranty is voided if repairs are made by an unauthorized dealer and/or the serial number data plate is removed and/or defaced. Normal deterioration of finish due to use or exposure is not covered by this Warranty. This Limited Warranty does not cover failure, damages or inadequate performance due to accident, acts of God (such as lightning), fluctuations in electric power, alterations, abuse, misuse, misapplications, corrosive-type atmospheres, improper installation, failure to operate in accordance with the Manufacturer's written instructions, abnormal use or commercial use. NuWave, LLC reserves the right to void the Limited Warranty, where allowable by law, for products purchased from an unauthorized dealer.