



CORDLESS 1-INCH VINYL MINI BLIND INSTRUCTIONS




INSTALLATION | OUTSIDE MOUNT

Marking Holes2 Installing BracketsMark the screw holes at the back
or top of the bracket **③**.Attach the brackets **③** with the screws **④**
provided and tighten the screws in place.

 Pre-drill holes for mounting screws and use level at top of brackets to ensure straight alignment.



When mounting brackets on wall board or plaster, use the anchors.




Insert the top front of the

head rail into the front


lip of the **brackets**. Push

3 Inserting

PREPARATION




INSTALLATION INSIDE MOUNT		
1 Marking Holes	2 Installing Brackets	3 Inserting
 Mark the screws holes at the back or top of the bracket (2). Pre-drill holes for mounting screws. For wider widths and added support, install the center support bracket when provided. Install at approximate center of the headrail. 	 Attach the brackets is with the screws in place. Use the provided spacers is when attaching the brackets to the ceiling or when the depth of the recess exceeds 1-1/2 inches. When mounting brackets on wall beard 	
	When mounting brackets on wall bo or plaster, use the anchors.	ard
	NOTE The spacer provides the minimum required space above the mounting bracket to install the headrail of the shade.	Use the spacers when mounting to the ceiling.



1. Insert the **tilter (**) into the tilt control mechanism in the **headrail (**) by aligning and pushing into the unit until it clicks and locks into place.



2. Hook the **wand** (C) through the hang hole in the **tilter** (C).



3. Rotate the wand clockwise or counterclockwise to open or close the blind slats.

Ouick How-to-use Guide Image: Constrained on the binds pull down from the bottom to the desired height.

Questions

EMAIL support@chicology.com

HOW - TO www.chicology.com/how-to



PHONE 866-999-6188 HARDWARE www.chicology.com/missing-hardware



Chicology Ready-Made Blinds and Shades Warranty

Limited One Year Warranty from the Date of Purchase

What is Covered :

• All of our shades are warranted against manufacturer defects in materials or workmanship provided that you are the original purchaser of the product, and the product was installed according to our instructions.

What is Not Covered :

- Normal wear and tear.
- Consumer damages caused by accidents, alterations, abuse of the product, exposure to salt air, misuse, or damages from pets or insects.
- Damages resulting from removal and reinstallation in the same or any other window or application, or failure to follow instructions, such as measurement, installation, cleaning, and maintenance.
- Any products that, with the passage of time, has yellowing or cracking of plastic parts
- Wrong measurements are not covered by the warranty and are not refundable.

To report shipping damages :

If damage occurred during shipping, please email support@chicology.com immediately and report within 14 calendar days or else you may be denied for your damaged product.

Obligations to the consumer :

The obligations of Chicology are limited to the repair or replacements of parts or products found to be defective. Chicology will determine if the product is defective or not and may replace the product. If the product is found to have manufacture defects, we will repair or replace the product. Colors do vary from lot to lot, and may not match original product exactly. Discontinued items will be replaced with the most current product of the same price.

Your Rights under State law :

This limited warranty gives you specific legal rights, and you may have other rights, which vary from state to state.

Contacting us :

If you believe your shade has a manufacturing defect, please email us at support@chicology.com