
Owner's Manual





Model No: HE-15072

These instructions contain 5 pages:

Page 1: Foreword

Page 2: Unpack and inspect parts contained, and pre-installation notes

Page 3: Hanging system installation

Page 4: Wiring connections and Canopy and Blade installation

Page 5: Light/Cover installation and Remote Setting

Net Weight

6.6 KGS

7.8 LBS

Toll Free 1-855-676-7247


READ AND SAVE THESE INSTRUCTIONS

WARNING: TO REDUCE THE RISK OF FIRE, ELECTRICAL SHOCK, OR INJURY TO PERSONS, PLEASE OBSERVE THE FOLLOWING:


- 1.] To ensure success of installation, be sure read these instructions and review the diagrams thoroughly before beginning.
- 2.] To avoid possible electric shock, be sure electricity is turned off at the main power box before wiring.

 All electrical connections must be made in accordance with local codes, ordinances and/or the National Electrical Code. If you are unfamiliar with the methods of installing electrical wiring and products, secure the services of a qualified and licensed electrician as well as someone who can check the strength of the supportive ceiling members and make the proper installations and connections.
- 3.] Make sure that your installation site will not allow rotating fan blades to come into contact with any object. Blades should be at least 7 feet from the floor when fan is in operation.
- 4.] If possible, mount ceiling fan on a ceiling joist the joist must be able to support the motion and weight of the moving fan. If the fan will be mounted on a ceiling outlet box, a 4" x 2 1/8" deep METAL octagon box is required; one UL listed as "suitable for fan support". The box and its supporting members must not be able to twist or work loose. DO NOT USE PLASTIC BOXES. Installation on a concrete ceiling should be performed by qualified personnel.
- 5.] Blades should be attached after motor housing is hung and in place. Fan motor housing should be kept in carton until ready to be installed to protect its finish. If you are installing more than one ceiling fan, make sure that you do not mix fan blade sets.
- 6.] After making electrical connections, spliced conductors should be turned upward and pushed carefully up into the outlet box. The wires should be spread apart with the grounded conductor and the equipment-grounding conductor on one side of the outlet box and the "HOT" wires on the other side.
- 7.] Electrical diagrams are for reference only. Light kits that are not packed with the fan must be UL/ETL listed and should be installed per the light kit's installation instructions.
- 8.] After fan is completely installed, check to make sure that all connections are secure to prevent fan from falling and/or causing damage or injury.
- 9.] The fan can be made to work immediately after installation. The bearings are adequately charged with grease, so that, under normal conditions, further lubrication should not be necessary.
- 10.1 The fan must be turned off and stopped before reversing fan direction.
- 11.] This fan is suitable for sloped ceiling.
- 12.] This fan is electrically reversible.
- 13.] This fan includes a light.
- 14.] This fan is controlled by remote control.
- 15.] This fan is suitable for indoor use.

Unpack and inspect fan carefully to be certain all contents are included.




WARNING: blades should be at least 7 feet from floor



1. HANGING SYSTEM INSTALLATION


1A. Installing mounting bracket to ceiling outlet box

Install mounting bracket to outlet box in ceiling by using screws included with the outlet box and washers from the hardware bag.




1B. Installing Downrod and Yoke

- (1) Remove cross pin, washer and cotter pin from downrod.
- ② Insert downrod through canopy and yoke cover, and feed motor wires through downrod.
- 3 Loosen 2 downrod jam screws at yoke. Insert downrod assembly into yoke.
- 4 Insert the cross pin through yoke & downrod and secure with washer and cotter pin.
- (5) Tighten both downrod jam screws to further secure downrod.



1C. Hanging the fan


- ① Lift fan assembly onto the mounting bracket.
- ② Rotate the fan so that the groove on the ball engages the ridge on the mounting bracket.



2. RECEIVER INSTALLATION

2. Insert receiver into mounting bracket

Note: Do not squeeze all the wires while inserting the receiver into the mounting bracket.




Mounting

Bracket

3. WIRING CONNECTIONS

- Green Ground/Earth to Green from Downrod and Green from Hanging Bracket
- Black Source to Black Input of Receiver
- Black Source to Black Input of ReceiverWhite Source to White Input of Receiver
- 4 Black Output from Receiver to Black Fan Wire
- 5 Blue Output from Receiver to Blue Fan Wire
- 6 White Output from Receiver to White Fan Wire



Secure with twist-lock wire nuts.

Make sure that all wires are secured inside wire nuts.


Note: Wires from house may vary in color and may not include ground wire (green). After wiring is complete, collect wires neatly inside mounting bracket.

4. CANOPY INSTALLATION

4. Installing the canopy

Note: Two screws are pre-installed on mounting bracket for canopy installation. You will need to remove one and loosen the other slightly.

- (1) Push up canopy until the screw still in the mounting bracket is engaged with the large end of the keyhole on canopy.
- 2 Rotate canopy slightly until the screw head is engaged in the narrow end of the key hole.
- (3) Insert the remaining canopy screw into the other hole, and tighten both canopy screws.




5. BLADE ARM INSTALLATION

5. Installing the blade arms

- (1) Raise blade arm to motor face. aligning the holes to the motor.
- 2 Secure blade to blade arm with blade arm screws.

Repeat for remaining blades.




6. BLADE INSTALLATION

6. Installing the blades

- ① Lay blade on top of blade arm aligning the four holes in blade with the four posts on blade arm.
- 2 Secure blade to blade arm with blade screws and washers.


Repeat for remaining blades.



7. LIGHT/COVER INSTALLATION


7a. Installing the Light Pan

- Remove one screw and loosen two screws from the central hub.
- ② Lift light pan to motor to engage the large end of the key holes with the screws.
- 3 Rotate the plate slightly to engage two screws in small ends of key holes.
- 4 Insert screw removed in step 1 and tighten all three screws.




7b. Installing the LED Array

- ① Remove three screws from the light pan.
- ② Plug in wire connectors, matching wire colors.
- ③ Lift LED array to light pan, aligning the outermost holes in LED plate to the outermost threaded holes in Light Pan.
- ④ Insert screws removed in step 1 and tighten all three screws.



7c. Installing the Light Cover

- ① Lift cover to motor aligning the opening of the grooves to the nibs inside the lower plate.
- ② Rotate cover clockwise to secure it to motor assembly.



8. REMOTE SETTING


8A. Preparing Remote Control

- ① Remove Battery Cover from Transmitter
- (2) Install 2 AAA Batteries

The model is equipped with dimmable LED array so the Light selector switch should remain on DIM setting.

8B. Remote Pairing Process

Transmitter and receiver must be paired to operate together, or to reset after replacing either transmitter or receiver module. (can also circumvent Radio Frequency Interference from another RF device.)



② Turn on the power.

Within 30 seconds of restoring power,

③ press and hold the Learn Switch button for 3 to 5 seconds, using narrow tool, pen or pencil tip.
The light on the fan will flash 3 times when complete.

4 Slide the Battery cover back on.

