

## FAQ

**Q1: How to know the working times for my device? Why does the duration of some devices deviate from the actual usage data?**

A: Working time =  $880\text{Wh} \times 0.85$  / operating power of your device. The duration of our equipment is based on laboratory data, and the duration of specific equipment usage may vary.

**Q2: Can the Explorer 880 be charged while using?**

A: Yes, Explorer 880 supports pass-through charging. But we don't suggest, it will cause damage to battery life.

**Q3: What devices can Explorer 880 power?**

A: Please note that the AC output port can only charge/power devices that operate at less than total 880 Watt.

**Q4: Does Explorer 880 include a built-in MPPT controller?**

A: All Jackery power stations have a built-in MPPT controller.