

D93-2, D398R
or R93-2




INSTRUCTIONS:

1. Remove old overflow plate.
2. Install new faceplate using screw provided.
3. Remove old drain body using plier handles or similar tool.
4. Apply Teflon™ tape to strainer body.
5. Making sure threads are clear of debris, screw in new drain body.



INSTRUCCIONES:

1. Quitar la placa usada del rebosadero.
2. Instale la placa nueva usando el tornillo provisto.
3. Desaloje el cuerpo del desagüe usando pinzas para manijas o una herramienta semejante.
4. Aplique cinta Teflon™ en el cuerpo del filtro.
5. Asegúrese que las roscas estén limpias, atornille el cuerpo nuevo del desagüe.



Troubleshooting Leaking Tip-Toe Bathtub Drains



Sometimes the tip-toe washer does not engage with the stopper, allowing the water to leak. This is how to resolve this.



D3322, D3323, D398R, D93, R931K, R93-2, etc.



Remove Cap from drain or the cartridge from the drain body



Fully Open the drain and remove the Cover Cap



Tighten Screw with Screw driver and reinstall drain and cover. It can also help to place silicone seal onto the washer surface to keep it moist,

