

# Ultimate Ro PH90 Installation Addendum

The steps for installing the RO PH90 is the same as the included manual. Please follow the directions in the **Installation Manual** from pages **1-13**.

**When you get to Step 6 "Connecting The System, Summary of Tubing Connections, Point H to Z" in the manual (page 13), please use this Addendum.**

**Point P to Z:** Connect product water from 6th stage PH Plus filter output to Ro faucet-Clear tubing.


The 5<sup>th</sup> stage carbon filter outflow (**point H**) will No longer connect to the faucet. The 5<sup>th</sup> stage filter has been rerouted into the PH Plus filter as stage 6. For **Step 5 (point H)** under "Details on Tubing Connections" in the manual (**page 15**), please follow below.

## **5. Point P- Stage 6 PH Plus filtered water to faucet connection.**

**Tubing color:** Clear tubing. Connect the CLEAR tubing from the faucet base stud to the PH filter's outflow end at **Point P**. ("Flow →" arrow on the filter is the output to faucet at **Point Z**).

**Fitting type:** Quick Connect. Please remove End Plug first, then simply push the Clear tubing into the QC fitting. No Inserts, Sleeves or Nuts are needed to secure the connection. No Teflon tape needed here.

Please refer back to **Step 6 on page 15** in the Owner's Manual to complete installation.



# PH Plus Filter Replacement Guide

The PH Plus (FI-PHPLUS-QC) filter should be replaced every **6-12 months**. Please follow the replacement steps below.

- 1) **Turn OFF** cold water supply to RO system. **Turn OFF** tank ball-valve by turning the blue handle 90 degrees. Lift up RO faucet lever briefly to relief the built-up pressure inside the Ro system. This will make removing the tubing easier.
- 2) Remove the **CLEAR outlet tubing at Point P**. See **Fig.1**. To remove the tubing Push In and hold down on the collet ring square against the fitting. With the collet held in this position the tube can be removed. Once the outlet tubing is disconnected, please remove the inlet tubing at **Point O**. Remove old filter and discard.
- 3) The new PH Plus filter will come with 2 End Plugs. Please **remove** the plugs before connecting the tubing to the filter.
- 4) To reconnect the tubing to **Point O and P**, push the tubing into the Quick Connect fitting, then gently pull back on the tubing to make sure the connection was secure.
- 5) Please drain a full tank of water before use.



Fig. 1