PRODUCT INTRODUCTION

- Please do not rush to connect the power supply after the stable placement and cleanness of the refrigerator. It should be stand for at least 2 hours, and then switch on the power to ensure the normal operation of the refrigerator.
- Place the refrigerator in the right place (see the foregoing points for attention), and make a full cleaning of the refrigerator before use (refer to the latter section of cleaning methods).of the refrigerator.
- Note: The power cord should not be pressed by the refrigerator itself and other heavy objects, so as to avoid damaging the power line and causing accidents.
- The temperature of refrigerating chamber is usually around 32-50°F, which is used to store fresh food for a short time, such as vegetables, fruits and beverages, etc..
- Refrigerated food should be wrapped in plastic wrap and placed evenly on the shelf to prevent taint of odor or excessive evaporation of moisture.
- The storage of goods in the refrigerating chamber should not be too dense. It should leave proper space for the cold air circulation.
 Hot food should be cooled to room temperature and then

put into the fridge.

Radish or similar food should cut off leaves to prevent nutrition from being absorbed by leaves.

- The amount of fresh food placed in the freezer should not exceed the freezing capacity listed in the technical parameters of the refrigerator.
- Minimize the number of opening and closing times to reduce the loss of cold air. So that the storage period can be extended.
- Note: It should be noted that food should not obstruct the air outlet when storing food, so as not to cause bad circulation of the cool air and affect the normal performance of the refrigerator.
- Frozen foods should not be refrozen after thawing. They should be eaten as quickly as possible.
- Use sealed packages or fresh-keeping bags to freeze food as far as possible, so that they can be stored for a longer time and can reduce freezer burn on the food chamber.
- After a loss of power, please reduce the number of open doors, and try not to put in the new food (to prevent the temperature in the cabinet to pick up faster).
- If a power outage is known change pick up to rise, you should make more ice cubes that placed in a watertight container, and put them in the upper of the refrigerating chamber.

PRODUCT INTRODUCTION

INSTRUCTION FOR USAGE

- When the refrigerator is not in use, please open the door to prevent the bad smell from the residue of the food in the refrigerator.
- The freezing drawer is used for storing something that need to be preserved for a long time, such as meat, fish and so on.
- Package the food to be frozen as flat as possible to facilitate freezing and thawing.
- After pulling off the power, it should be kept the refrigerator at least 5 minutes apart before it is reenergized. vertically, so that the storage period can be extended.
- The food that can be washed is best to be stored after cleaning and drying.
- If the refrigerator needs to be stopped for a long time, the power plug should be removed, the power should be cut off, and the refrigerator should be cleaned according to the method described above. In general, do not block up the refrigerator, otherwise it will affect the service life of the refrigerator.

USAGE

MAINTENANCE AND CLEANING

Defrost

This product is frost-free refrigerator, and there is no need for manual defrosting.

Cleaning


- The refrigerator should be cleaned often to avoid unpleasant smells.
- Before cleaning, you must remove the plug.




- Use a soft towel or sponge dipped in warm water (neutral detergent can be added) to clean the cabinet except the door seal. When the door seal is cleaned, you must use rinsing and wipe it with dry cloth.
- **Note:** Do not spray the water directly when cleaning, so as not to affect the insulation performance of electrical components. Use a dry rag when cleaning electrical components such as switch and light.
- Note: Do not use hard brushes, wire brushes, detergents, gasoline, lacquer thinner, acetone and other organic solvents, hot water or acid, alkali to clean the refrigerator.

PRODUCT INTRODUCTION


DOOR HANDLE INSTALLATION




1. Before the refrigerator door handle is installed (note: the anchor bolts of the handle are in the accessory bag, and all steps should be performed at the right and left two mounting positions simultaneously.



3. Loosen the locking screw inside the handle part with a hexagonal wrench first, then align the handle with the positioning bolt and insert it into the positioning bolt (note: the handle locking screw is installed facing down).




2. Screw the locating bolt into the bolt hole of the door body and secure it.



4. Wait until the handle fits perfectly with the door body, and then use a hexagonal wrench to tighten the locking screw inside the handle part.


INSTRUCTION FOR USAGE




5. Finish installing the handle.

Installing door bin:

tray off upward.






1. Place the tray above the mounting position and force the door up to the bottom, completing the installation when it cannot continue to move down.

Door Mullion

When the door mullion is positioned unfolded as illustrated in figure 1, the door will not close properly. Please fold the door mullion inside as shown in figure 2 before closing the door. In order to prevent damage, do not try to close the door when the mullion is unfolded as shown in figure 1.





Notice: in order to prevent condensation, the door mullion is provided with heater for heating. Door mullion heating is normal phenomenon and has no effect on frozen food.