

Installation

SCHIENE, DECO, RENO-TK, RENO-U, RENO-RAMP, and RENO-V

1. Select the profile according to tile thickness and format.
Note: When using Schluter® uncoupling membranes with RENO-U and RENORAMP profiles, factor in the thickness of the membrane over the anchoring leg when selecting the profile height.
2. Using a notched trowel, apply thin-set mortar to the area where the profile is to be placed.
For RENO-U and RENO-RAMP, fill the cavity beneath the sloped section of the profile with thin-set mortar. Follow this step when RENO-V is used in heavy-duty applications, as well.
3. Press the perforated anchoring leg of the profile into the mortar and align.
4. Trowel additional thin-set mortar over the perforated anchoring leg to ensure full coverage and support of the tile edges.
5. Solidly embed the tiles so that the tiled surface is flush with the top of the profile; the profile should not be higher than the tiled surface, but rather up to approx. 1/32" (1 mm) lower.
6. Set the tile to the integrated joint spacer, which ensures a uniform joint of 1/16" - 1/8" (1.5 - 3 mm). For DECO and stainless steel profiles, leave a space of approximately 1/16" - 1/8" (1.5 - 3 mm).
7. Fill the joint completely with grout or setting material.
8. Remove grout or mortar residue from the visible surface of the profile.

RENO-RAMP-K

1. Fill the cavity beneath the sloped section of the profile with thin-set mortar.
2. Using a notched trowel, apply thin-set mortar to the area where the profile is to be placed.
3. Press the profile into the mortar and abut to the adjacent floor covering. The profile should not be higher than the adjacent floor covering, but rather up to approx. 1/32" (1 mm) lower.
4. Fill the joint completely with grout or setting material.
5. Work with materials and tools that will not scratch or damage sensitive surfaces. Setting materials must be removed immediately.

RENO-T

1. Select the profile according to joint width, to ensure proper support of the lateral crosspiece.
2. The joint cavity must be at least 3/8" (9 mm) deep and free of debris. Substances that inhibit adhesion must be removed from the sides of the joint.
3. Fill the joint with elastomeric sealant such as Schluter®-KERDI-FIX or similar. Then insert the vertical leg of RENO-T in the joint so that the lateral crosspiece rests completely on the edges of the surface coverings.
4. Remove any excess sealant with a suitable cleaner.