


# HOME DECORATORS COLLECTION

SK19170AR1 PRESCOTT MODULAR PANTRY TOP 47-3/8"Hx47-3/4"Wx20"D

INV#99506













## ASSEMBLY INSTRUCTIONS

Made In China




Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment. Count all parts and material hardware, then compare with parts list to be sure all parts are present. If any parts are missing or damaged, phone, fax, or mail to our Customer service Department for efficient and speedy service. Please indicate the model number and code letter of part(s) needed.

**IMPORTANT NOTE:** Follow instructions listed below in proper sequence as numbered to assure fast,easy and correct assembly.


PARTS LIST		
<b>A</b>  TOP PANEL-1PC	<b>B</b>  LEFT SIDE PANEL-1PC	<b>C</b>  RIGHT SIDE PANEL-1PC
<b>D</b>  CROSS BRACE-1PC	<b>E</b>  RIGHT PARTITION-1PC	<b>F</b>  LEFT PARTITION-1PC
<b>G</b>  SMALL PARTITION-1PC	<b>H</b>  MIDDLE FIXED PANEL-1PC	<b>I</b>  RIGHT FIXED PANEL-1PC
<b>J</b>  LEFT FIXED PANEL-1PC	<b>K</b>  ADJUSTABLE SHELF-3PCS	<b>L</b>  LEFT DOOR-1PC

M




RIGHT DOOR-1PC

N




SIDE BACK PANEL-2PCS

O




MIDDLE BACK PANEL-1PC

P




DRAWER FRONT PANEL-2PCS

Q




DRAWER LEFT  
SIDE PANEL-2PCS

R




DRAWER RIGHT  
SIDE PANEL-2PCS

S




DRAWER BACK PANEL-2PCS

T





























DRAWER  
BOTTOM PANEL-2PCS

U




BOTTOM PANEL-1PC

NOTE:THE SURFACE WITH THE STICKER IS THE BACK SIDE

<div>a</div> <div></div> <div>WOOD DOWEL-33PCS</div>	<div>b</div> <div></div> <div>CAM LOCK BOLT-26PCS</div>	<div>c</div> <div></div> <div>CAM LOCK-26PCS</div>	
<div>d</div> <div></div> <div>LONG PLASTIC COVER-18PCS</div>	<div>e</div> <div></div> <div>SHORT PLASTIC COVER-4PCS</div>	<div>f</div> <div></div> <div>5/8" L ROUND HEAD SCREW-48PCS</div>	
<div>g</div> <div></div> <div>METAL PLATE-7PCS</div>	<div>h</div> <div></div> <div>HINGE-4PCS</div>	<div>i</div> <div></div> <div>1/2" L FLAT HEAD SCREW-28PCS</div>	
<div>j</div> <div></div> <div>KNOB-2PCS</div>	<div>k</div> <div></div> <div>KNOB BOLT-2PCS</div>	<div>l</div> <div></div> <div>1" L FLAT HEAD SCREW-8PCS</div>	
<div>m</div> <div></div> <div>MAGNET-1PC</div>	<div>n</div> <div></div> <div>SHELF PIN-12PCS</div>	<div>o</div> <div></div> <div>CARD CLIP PLATE-2PCS</div>	<div>p</div> <div></div> <div>10mm L FLAT HEAD SCREW-4PCS</div>
<div>q</div> <div></div> <div>BOLT-4PCS</div>	<div>r</div> <div></div> <div>WASHER-4PCS</div>	<div>s</div> <div></div> <div>SPRING WASHER 4PCS</div>	<div>t</div> <div></div> <div>ALLEN WRENCH-1PC</div>
<div>u</div> <div></div> <div>SHORT CAM SCREW-12PCS</div>	<div><div><div><div>1</div><div></div><div>x4 RECTANGLE METAL PLATE</div></div><div><div>2</div><div></div><div>x2 5/8" L FLAT HEAD SCREW</div></div><div><div>3</div><div></div><div>x2 PLASTIC ANCHOR</div></div><div><div>4</div><div></div><div>x2 PLASTIC BAND</div></div><div><div>5</div><div></div><div>x2 1-1/2" L FLAT HEAD SCREW</div></div></div><div>ANTI-TIPPING HARDWARE PACKAGE</div></div>		



NOTE:THE SURFACE WITH THE STICKER IS THE BACK SIDE

## HOW TO SEPARATE GLIDES





PRIOR TO ASSEMBLY, WE SUGGEST SEPARATING THE INNER GLIDES FROM THE OUTER-GLIDES, SIMPLY PULL THE LEFT/RIGHT INNER GLIDES FROM THE OUTER GLIDES EXPOSING A SMALL BLACK SAFETY RELEASE TAB, BY PUSHING THE SAFETY RELEASE TAB. YOU WILL BE ABLE TO SEPARATE THE GLIDES.

NOTE: • UPON OPENING, THOROUGHLY CLEAN ALL WOOD SURFACES TO REMOVE DUST AND DIRT THAT MAY HAVE SETTLED ONTO THE FINISH DURING SHIPMENT. IN ORDER TO PREVENT DAMAGE DURING ASSEMBLY. PLEASE ASSEMBLE THIS ITEM WITH AT LEAST TWO PEOPLE.




NOTE: TURN THE CAM-BOLT SCREWS UNTIL THEY ARE TIGHT, THE SHOULDER SHOULD BE AGAINST THE SURFACE OF THE PART.

## HOW TO USE THE CAM-TOOL




NOTE: • THE ARROWS ON THE HIDDEN CAM-LOCKS SHOULD POINT TO THE CAM-BOLTS.

# FIG 1




- TIGHTEN THE HINGE (h) ONTO THE LEFT SIDE PANEL (B) AND THE RIGHT SIDE PANEL (C) BY USING THE 1/2"L FLAT HEAD SCREW (i).

# FIG 2




9950720410  
9950720210

NOTE : 9950720410/9950720210 ONLY USE  
WOOD DOWEL.



9950700410  
9950700210




9950710410  
9950710210

- INSTALL THE WOOD DOWEL (a) AND THE CAM LOCK BOLT (b) INTO THE BOTTOM PANEL (U) AS SHOWN (NOTE :9950720410/9950720210 ONLY USE WOOD DOWEL).
- JOIN THE BOTTOM PANEL (U) TO THE ASSEMBLED BASE BY USING THE WOOD DOWEL (a) FIRST.
- TIGHTEN CAM LOCK BOLT (b) WITH THE CAM LOCK (c) IN THE PRE-DRILLED HOLES.
- COVER THE CAM HOLES WITH THE LONG PLASTIC COVER (d) AS SHOWN.




# FIG 3




- INSTALL THE WOOD DOWEL (a) INTO THE RIGHT SIDE PANEL (C) AS SHOWN.
- JOIN THE RIGHT SIDE PANEL (C) TO THE BOTTOM PANEL (U) BY USING THE WOOD DOWEL (a), THE BOLT (q), THE SPRING WASHER (s) AND THE FLAT WASHER (r) AS SHOWN. TIGHTEN THE BOLT (q) WITH THE ALLEN WRENCH (t).

# FIG 4




- INSTALL THE WOOD DOWEL (a) AND THE CAM LOCK BOLT (b) INTO THE BOTTOM PANEL (U) AS SHOWN .
- JOIN THE RIGHT PARTITION (E) TO THE BOTTOM PANEL (U) BY USING THE WOOD DOWEL (a) FIRST.
- TIGHTEN CAM LOCK BOLT (b) WITH THE CAM LOCK (c) IN THE PRE-DRILLED HOLES.
- COVER THE CAM HOLES WITH THE LONG PLASTIC COVER (d) AS SHOWN.

# FIG 5




- INSTALL THE SHORT CAM SCREW (u) INTO THE RIGHT PARTITION (E) AND THE RIGHT SIDE PANEL (C).
- JOIN THE RIGHT FIXED PANEL (I) TO THE RIGHT PARTITION (E) AND THE RIGHT SIDE PANEL (C) BY THE CONNECTOR AS SHOWN.

# FIG 6




- INSTALL THE WOOD DOWEL (a) AND THE CAM LOCK BOLT (b) INTO THE BOTTOM PANEL (U) AS SHOWN .
- JOIN THE LEFT PARTITION (F) TO THE BOTTOM PANEL (U) BY USING THE WOOD DOWEL (a) FIRST.
- TIGHTEN CAM LOCK BOLT (b) WITH THE CAM LOCK (c) IN THE PRE-DRILLED HOLES.
- COVER THE CAM HOLES WITH THE LONG PLASTIC COVER (d) AS SHOWN.

# FIG 7




- INSTALL THE SHORT CAM SCREW (u) INTO THE RIGHT PARTITION (E) AND THE LEFT PARTITION (F).
- JOIN THE MIDDLE FIXED PANEL (H) TO THE RIGHT PARTITION (E) AND THE LEFT PARTITION (F) BY THE CONNECTOR AS SHOWN.

# FIG 8




- INSTALL THE WOOD DOWEL (a) INTO THE LEFT SIDE PANEL (B) AS SHOWN.
- JOIN THE LEFT SIDE PANEL (B) TO THE BOTTOM PANEL (U) BY USING THE WOOD DOWEL (a), THE BOLT (q), THE SPRING WASHER (s) AND THE FLAT WASHER (r) AS SHOWN. TIGHTEN THE BOLT (q) WITH THE ALLEN WRENCH (t).

# FIG 9



- INSTALL THE SHORT CAM SCREW (u) INTO THE LEFT SIDE PANEL (B) AND THE RIGHT PARTITION (E) AS SHOWN.
- INSTALL THE WOOD DOWEL (a) AND THE CAM LOCK BOLT (b) INTO THE FIXED PANEL (J).
- JOIN THE LEFT FIXED PANEL (J) TO THE LEFT PARTITION (F) BY USING THE WOOD DOWEL (a) FIRST.
- JOIN THE LEFT FIXED PANEL (J) TO THE LEFT SIDE PANEL (B) AND THE RIGHT PARTITION (E) BY THE CONNECTOR AS SHOWN.
- TIGHTEN CAM LOCK BOLT (b) WITH THE CAM LOCK (c) IN THE PRE-DRILLED HOLES.
- COVER THE CAM HOLES WITH THE LONG PLASTIC COVER (d) AS SHOWN.


# FIG 10



- ATTACH THE MAGNET (m) ONTO THE CROSS BRACE (D) BY USING THE 5/8" L ROUND HEAD SCREW (f) AS SHOWN.
- INSTALL THE WOOD DOWEL (a) AND THE CAM LOCK BOLT (b) INTO THE TOP PANEL (A).
- JOIN THE CROSS BRACE (D) TO THE TOP PANEL (A) BY USING THE WOOD DOWEL (a) FIRST.
- TIGHTEN CAM LOCK BOLT (b) WITH THE CAM LOCK (c) IN THE PRE-DRILLED HOLES.




# FIG 11




- INSTALL THE WOOD DOWEL (a) AND THE CAM LOCK BOLT (b) INTO THE TOP PANEL (A).
- JOIN THE TOP PANEL (A) TO THE ASSEMBLED PART BY USING THE WOOD DOWEL (a) FIRST.
- TIGHTEN CAM LOCK BOLT (b) WITH THE CAM LOCK (c) IN THE PRE-DRILLED HOLES.
- COVER THE CAM HOLES WITH THE LONG PLASTIC COVER (d) AS SHOWN.

# FIG 12




- TIGHTEN THE SIDE BACK PANEL (N), THE MIDDLE BACK PANEL (O) AND THE BACK PANEL OF THE BASE BY USING THE 5/8"L ROUND HEAD SCREW (f) AND THE METAL PLATE (g) AS SHOWN.

# FIG 13




- INSTALL THE WOOD DOWEL (a) AND THE CAM LOCK BOLT (b) INTO THE DRAWER FRONT PANEL (P).
- JOIN THE DRAWER LEFT SIDE PANEL (Q) AND THE DRAWER RIGHT SIDE PANEL (R) TO THE DRAWER FRONT PANEL (P).
- ONCE JOINED, TIGHTEN CAM LOCK (c) ONTO THE CAM LOCK BOLT (b) USING PRE-DRILLED HOLES.
- COVER CAM HOLES WITH THE SHORT PLASTIC COVER (e).
- SLIDE THE DRAWER BOTTOM PANEL (T) INTO THE GROOVES ON THE DRAWER LEFT SIDE PANEL (Q) AND THE DRAWER RIGHT SIDE PANEL (R).
- JOIN THE DRAWER BACK PANEL (S) TO THE ASSEMBLED DRAWER PART AND TIGHTEN THE DRAWER BACK PANEL (S) BY USING THE 1" L FLAT HEAD SCREW (I) THROUGH PRE-DRILLED HOLES ON DRAWER SIDE PANELS.
- TIGHTEN THE CARD CLIP PLATE (o) TO THE DRAWER FRONT PANEL (P) BY USING THE 10MM L FLAT HEAD SCREW (p).

# FIG 14




- INSERT DRAWERS INTO THE ASSEMBLED PART.

# FIG 15




- TIGHTEN THE KNOB (j) ONTO THE LEFT DOOR (L) AND THE RIGHT DOOR (M) BY USING THE KNOB BOLT (k) AS SHOWN.

# FIG 16




- INSERT THE SHELF PIN (n) IN THE DESIRED POSITION AND THEN PLACE THE ADJUSTABLE SHELF (K) ON THE PINS.
- ATTACH THE LEFT DOOR (L) AND THE RIGHT DOOR (M) TO THE ASSEMBLED PART BY USING THE 1/2" L FLAT HEAD SCREW (i).

# FIG 17



- TIGHTEN THE RECTANGLE METAL PLATE (1) TO THE REAR OF THE TOP PANEL (A) BY USING 1/2" FLAT HEAD SCREW (2).
- PLACE THE ASSEMBLED PRESCOTT MODULAR PANTRY TOP AT THE DESIRED POSITION. MARK THE INSERTION POINTS FOR THE PLASTIC ANCHOR (3).
- USING THE PROPER HARDWARE FOR YOUR WALL TYPE, DRILL 1/4" HOLES INTO THE WALL.
- TIGHTEN THE RECTANGLE METAL PLATE (1) TO THE PLASTIC ANCHOR (3) BY USING THE 1-1/2" FLAT HEAD SCREW (5).

# FIG 18



- USING THE PLASTIC BAND (4) CONNECT TWO RECTANGLE METAL PLATES (1).