


ENCLO

HIDE IT WITH STYLE



Belmont Freestanding Lattice Screen W/ Planter Box

(45 1/2" H X 42" W X 14 7/8" L)

45 min

Approximate assembly time



Scan the QR code
for an assembly video



ASSEMBLY INSTRUCTIONS

www.encloscreens.com

VER. 120523

GENERAL INFORMATION



IMPORTANT

- ◀ A cordless drill with a Phillips head bit will be required for the assembly of this product.
- ◀ Check the inside of the larger pieces in your box for other materials packed inside.
- ◀ When assembling components, place on a non-abrasive surface (i.e. shipping box) to avoid scratching.
- ◀ We recommend an area approximately 5'x 8' for unobstructed assembling.
- ◀ You should not need to use excessive force when assembling components.

MISSING OR DAMAGED PARTS?

VISIT OUR WEBSITE FIRST, SO WE CAN HELP YOU RIGHT AWAY!

Although great care has been taken to ensure proper packaging and handling of this product, occasionally problems occur. If you discover any missing, damaged or defective parts, please visit our website to order replacement parts. If you experience any further trouble with your product, please contact our customer service department.

 parts.nychbrands.com

 support@encloscreens.com

 **704-892-5222 / 877-234-6196**

Customer service agents are available to take calls weekdays from 9am-5pm EST. If you call outside of business hours, please leave a voicemail.

To help you quickly and accurately, please have reference item number **EC18032** and the specific part name which can be found on page 4. It is helpful if you can provide the batch lot which is a stamped number on the end of the box.


NEED ASSEMBLY HELP?

If you are having problems with the assembly or installation of this product, we are happy to assist you with the process, **so please give us a call at 704-892-5222 / 877-234-6196.**

NEED TO RETURN?


If for some reason you need to return this product, please allow us to help resolve your issues first. If you still decide to return the product, **you will need to initiate the return from the company you originally purchased from.**

Detailed Product Dimensions & Specifications



Planter Box Volume
30 quarts


Planter Box Depth
4.7 in



RECCOMENDED TOOLS

PRODUCT ASSEMBLY

RECCOMENDED TOOLS




► Power Drill with Phillips Bit


SURFACE MOUNTED INSTALLATION (OPTIONAL)

- ! Recommended if installing into high wind environment
- ! Surface mounting screws not included

DIRT




► Hammer




► 3/4" Rebar (2)

DECK




► Power Drill
► Wood Drill Bit




► 1/4" Lag Screws
3" Length (4)
► Matching Driver Bit

PATIO



















► Hammer Drill
► Concrete Drill Bit



► 1/4" Concrete Screws
2 1/4" Length (4)
► Matching Driver Bit


STEP 1: LAY OUT MATERIALS

<div>A</div> <div></div> <div>Side Board (2) 7⁄8" x 10⁷⁄₈" x 7¼"</div>	<div>B</div> <div></div> <div>Long Board (2) 7⁄8" x 7¼" x 38"</div>	<div>C</div> <div></div> <div>Floor Board (1) 7⁄8" x 11" x 38"</div>
<div>D</div> <div></div> <div>Floor Support (2) 7⁄8" x 1½" x 7"</div>	<div>E</div> <div></div> <div>Post Cap (4)</div>	<div>F</div> <div></div> <div>Short Post (2) 3" x 3" x 10"</div>
<div>G</div> <div></div> <div>Long Post (2) 3" x 3" x 44"</div>	<div>H</div> <div></div> <div>Arched Top Rail (1) 7⁄8" x 8½" x 38"</div>	<div>I</div> <div></div> <div>Bottom Rail (1) 7⁄8" x 3" x 38"</div>
<div>J</div> <div></div> <div>Horizontal Slat (7) Slat 1 (6) ¼" x 1¼" x 38" Slat 2 (1) ¼" x 1¼" x 33½"</div>	<div>K</div> <div></div> <div>Vertical Picket (11) Picket 1 (3) ⅝" x ⅝" x 35½" Picket 2 (2) ⅝" x ⅝" x 35" Picket 3 (2) ⅝" x ⅝" x 34¼" Picket 4 (2) ⅝" x ⅝" x 33" Picket 5 (2) ⅝" x ⅝" x 31½"</div>	<div>L</div> <div></div> <div>2½" Self-Drilling Stainless Steel Screw (12)</div>
<div>M</div> <div></div> <div>Spacer (2) ¾" x 1" x 2"</div>	<div>N</div> <div></div> <div>Galvanized Steel L Bracket (2)</div>	<div>O</div> <div></div> <div>⅛ Drill Bit (1)</div>
		<div>P</div> <div></div> <div>1½" Self-Drilling Stainless Steel Screw(6)</div>

STEP 2: ASSEMBLE PLANTER BOX


STEP 2.1

- Lay out the Long Posts (**G**). Align the posts so the pre-drilled holes match what is shown in step 2.3 and slide (1) Long Board (**B**) into the post channels as shown.




STEP 2.2

- Slide (2) Side Boards (**A**) into the post channels as shown.




STEP 2.3

- Drive (8) 2 1/2" Self-Drilling Stainless Steel Screws (**L**) through the pre-drilled holes in the posts as shown below.




STEP 2.4

- Insert (2) Floor Supports (**D**) into the long board as shown.




STEP 2.5

- Align (2) Short Posts (**F**) so the pre-drilled holes match what is shown in step 2.7 and slide (1) Long Board (**B**) into the post channels as shown.




STEP 2.7

- Drive (8) 2 1/2" Self-Drilling Stainless Steel Screws (**L**) through the pre-drilled holes in the posts as shown below.




STEP 2.6



STEP 2.8


- Drop (1) Floor Board (**C**) into the planter box frame.



STEP 3: ASSEMBLE LATTICE SECTION


STEP 3.1

1. Insert the Vertical Pickets (K) into the Bottom Rail (I) in the pattern shown.
2. Insert the shorter Horizontal Slat 2 (J) into the top routed picket holes.



STEP 3.2


1. Install the Arched Top Rail (H) over the vertical slats and horizontal slat 2.
2. Insert (6) horizontal slat 1 pieces into the routed holes in the vertical pickets.



STEP 4: INSTALL LATTICE SECTION


STEP 4.1

1. Slide (2) Spacers (**M**) into the inner post channels of the long posts as shown.
2. Slide the assembled lattice section into the inner post channels of the long posts.



STEP 4.2

1. Pre-drill holes for (6) screws in the locations shown, with the included $\frac{1}{8}$ " drill bit (**O**).
2. Drive (6) $2\frac{1}{2}$ " self-drilling stainless steel screws into the back of the tall posts as shown below to secure the lattice section.
3. Remove spacers after screws have been installed.




STEP 5: INSERT POST CAPS

STEP 5.1

- Fit (4) Post Caps (**E**) over the short and tall posts.

Note: If you would like to secure your post caps, apply a small amount of vinyl glue to the inside rim of the caps to fix them to the posts.




SURFACE MOUNTED INSTALLATION (OPTIONAL)


- ! Recommended if installing into high wind environment
- ! Surface mounting screws not included

DIRT

STEP 6



- Hammer




- 3/4" Rebar (2)


OR

DECK

STEP 7



- Power Drill
- Wood Drill Bit




- 1/4" Lag Screws
3" Length (4)
- Matching Driver Bit


OR

PATIO

STEP 7



- Hammer Drill
- Concrete Drill Bit




- 1/4" Concrete Screws
2 1/4" Length (4)
- Matching Driver Bit


Recommended if installing into
high wind environment

STEP 6: DIRT INSTALLATION (OPTIONAL)

6.1




6.2




Recommended if installing into
high wind environment

STEP 7: PATIO / DECK INSTALLATION (OPTIONAL)


7.1



7.2




7.3



Drill and install
mounting screws
according to instructions
on screw packaging
(mounting screws
not included)

7.4



Repeat steps
for left side



HIDE IT WITH STYLE

www.encloscreens.com

support@encloscreens.com



704-892-5222
877-234-6196



6935 Reames Rd. Ste. K.
Charlotte, NC 28216



ASSEMBLY
INSTRUCTIONS