

installation instructions:

# PVC PILASTERS

## SAFETY INSTRUCTIONS

Make sure to use the correct tools recommended.

Wear safety goggles.

Follow fixture, power tools, and paint manufacturers' instructions and users manuals.

Use common sense and follow good construction practices.

## TOOL & MATERIAL CHECKLIST

- construction adhesive
- caulking gun
- electric drill
- miter saw
- noncorrosive screws

### IMPORTANT INFO


- It is highly recommended that you paint or finish pilaster before you install it.
- Place pilaster in room 2 to 3 days prior to installation. This allows the moulding to adjust to the temperature of the room.
- Hot-dipped galvanized or stainless steel nails/screws are best for PVC products.
- Fill fastener holes in with PVC acrylic caulk.
- Use 100% acrylic paint before in stalling, finish with final coat to cover caulked holes.

## INSTALL INSTRUCTIONS:

1. Measure the distance from the landing floor to the top of the brickmoulding.
2. Cut the pilaster to 3/16" longer than the top of the brickmoulding.  
**Note:** always trim from the bottom of the pilaster
3. Adhere using premium acrylic construction adhesive and any necessary fasteners for additional support.
4. Use caulk to seal edges. Use a finger or putty knife to smooth caulk.
5. Once caulk is dry, touch up using a high quality acrylic paint.

Note: If new construction, after installation of the pilasters butt and fit the manufacturers recommended J-Channel to the sides of the moulding.

## EXAMPLE DIAGRAM:



We Can Help. Call (866) 607-0453



**EKENA**  
MILLWORK

Industry leading manufacturer of urethane, PVC, wood, rustic, and metal millwork

[www.ekenamillwork.com](http://www.ekenamillwork.com)