




NANTUCKET VINYL PICKET GATE WITH WITH STAINLESS STEEL HARDWARE (48"H X 48"W)

60 MIN
Approximate assembly time

Want to see a video on how to
assemble this product?
Scan the QR code



ASSEMBLY INSTRUCTIONS BL19102



GENERAL INFORMATION



IMPORTANT

- + Check the inside of the larger pieces in your box for other materials packed inside.
- + When assembling components, place on a non-abrasive surface (i.e. shipping box) to avoid scratching.
- + We recommend an area approximately 5'x 8' for unobstructed assembling.
- + You should not need to use excessive force when assembling components.

MISSING OR DAMAGED PARTS?

VISIT OUR WEBSITE FIRST, SO WE CAN HELP YOU RIGHT AWAY!

Although great care has been taken to ensure proper packaging and handling of this product, occasionally problems occur. If you discover any missing, damaged, or defective parts, please visit our website to order replacement parts. If you experience any further trouble with your product, please contact our customer service department.

- parts.nychbrands.com
- hmmm@wambamfence.com
- 704-892-5222 / 877-778-5733**

Customer service agents are available to take calls weekdays from 9am-5pm EST. If you call outside of business hours, please leave a voicemail.

To help you quickly and accurately, please have reference item number **BL19102** and the specific part name which can be found on page 5. It is helpful if you can provide the batch lot which is a stamped number on the inside of the box.

NEED ASSEMBLY HELP?

If you are having problems with the assembly or installation of this product, we are happy to assist you with the process, **so please give us a call at 704-892-5222 / 877-778-5733.**

NEED TO RETURN?

If for some reason you need to return this product, please allow us to help resolve your issues first. If you still decide to return the product, **you will need to initiate the return from the company you originally purchased from.**

GENERAL INFORMATION

1. Read over fence instructions first.

Your gate and fence will work better together if you first take the time to read and understand your fence.

2. Pre-assemble the gate frame.

Please do not screw the gate frame together until you have temporarily assembled the gate frame. In other words, do a dry run first. This will ensure:

1. That you have everything necessary to complete the gate.
2. That you will have assembled the gate frame in the correct order.
3. All of the pieces fit and function properly.
4. The gate height and width are similar to the measurements shown on page four.


It's easier to troubleshoot when things are not screwed together. After you assemble your gate correctly, please disassemble as necessary, and use the 1½" self-drilling stainless steel screws to permanently assemble the gate.

3. Install your gate posts before your fence posts.



Your fence panels will be more forgiving for a custom fit than your gate. Position and install your gate posts before you do anything else.

4. Do not hang your gate system off a single non-supported post.

Your gate will perform better and last longer if your hinge post is connected to a panel of fence that is connected to another post. This way, the weight strain will be transferred onto two posts versus just one. Installing fence panels on both sides of your gate is ideal in all situations. If this is not possible because of space restrictions, please contact us for alternative solutions.




DETAILED PRODUCT DIMENSIONS AND SPECIFICATIONS



.090in. wall thickness


STEP 1: LAY OUT MATERIALS



STEP 2: ASSEMBLE GATE FRAME


STEP 2.1 ►

- Insert the Bottom Rail (**D**) all the way into the Gate Bottom Bracket (**B**) until it hits the corner of the gate bottom bracket as illustrated.




STEP 2.2 ►

- Insert the bottom rail all the way into the opposite gate bottom bracket until it hits the corner as illustrated.




STEP 2.3 ►

- Ensure the bottom rail hits the back of the bottom brackets as illustrated. Measure the distance between the two bottom brackets to ensure the width is 48 inches.




STEP 2.4 ►

- Insert (2) Vertical Stiles (**F**) into the gate bottom brackets until they hit the bottom rail.




STEP 2.4


- Insert the Top Rail (**E**) all the way into a T-Bracket (**C**) until it hits the back as illustrated.

**STEP 2.5**

- Insert the top rail all the way into the opposite T-bracket until it hits the back as illustrated.

**STEP 2.6**


- Slide the assembled gate frame top down over the vertical stiles.



STEP 3: SCREW GATE FRAME TOGETHER

STEP 3.1 ➤


- ▶ Fasten the gate frame together using (16) 1 $\frac{1}{4}$ " Self-Drilling Stainless Steel Screws (H).



STEP 4: INSERT PICKETS INTO GATE FRAME AND ATTACH POST CAPS


STEP 4.1 ▶

- ▶ Insert Pickets (G) through the top rail and down into the bottom rail.



STEP 4.2 ▶


- ▶ Install Post Caps (A) as illustrated. Use PVC glue (not included) if you would like to permanently secure the post caps to the T-brackets.



STEP 5: FASTEN GATE HINGES AND LATCH FINGER

STEP 5.1 ▶


1. Fasten the Latch Finger (K) to the top bracket with (6) 1 $\frac{1}{4}$ " black self-drilling stainless steel screws.
2. Fasten the Hinge (I) to the brackets with (12) total 1 $\frac{1}{4}$ " black self-drilling stainless steel screws.



STEP 6: ALIGN AND SECURE GATE HINGES TO POST

STEP 6.1 ➤


- ▶ Use temporary spacers or wooden blocks to rest the gate on during alignment and installation. Fasten the gate hinges to the post using (6) 1¼" black stainless steel screws.



STEP 7: LEVEL GATE AND ADJUST HINGES


STEP 7.1 ➤

- ▶ Fasten the gate hinges to the inside of the fence post with (8) total 1¼" black self-drilling stainless steel screws by swinging the gate out as illustrated.



STEP 7.2

- ▶ Level the gate to the fence post. Check the gate to make sure it functions correctly.




Note: The hinges can be adjusted moderately to level gate.

Note: To adjust the spring tension in the hinges, use the 2 $\frac{3}{4}$ " Tension Pin (L).

STEP 8: ALIGN AND INSTALL LATCH**STEP 8.1**

- ▶ Align and fasten the Latch Catch (J) with (6) 1 $\frac{1}{4}$ " black self-drilling stainless steel screws.



Note: Latch is designed for left and right hand applications. To reverse latch, temporarily remove the spring and bolt, and reverse paddle portion as necessary.



6935 Reames Rd. Ste. K.
Charlotte, NC 28216



hmmm@wambamfence.com

704-892-5222
877-778-5733



WWW.WAMBAMFENCE.COM

