

Hammock Swing Chair User Manual

Thank you for choosing this hammock swing chair. This manual contains important information for the safe assembly, use, and care of your product. Please read it thoroughly before use to ensure years of comfortable enjoyment.

Safety Warning

- Weight Limit:** The maximum weight capacity for this chair is 330 lbs (150 kg). Do not exceed this limit.
- Secure Installation:** Ensure the chair is suspended from a support structure (e.g., a sturdy ceiling beam or a dedicated stand) that is capable of supporting the combined weight of the chair and the user.
- Inspect Before Use:** Regularly check all ropes, knots, and the metal frame for signs of wear, fraying, or damage before sitting. Do not use the chair if any components are damaged.
- Supervise Children:** Always supervise children when they are using the swing chair.

1. Product Overview

Your swing chair is designed for comfort and style. Its key features include:

- Hand-Woven Seat:** The seat is meticulously hand-woven from soft cotton ropes, making it breathable, comfortable, and aesthetically pleasing.
- Decorative Tassels:** Elegant tassels add a delicate, bohemian charm, making the chair a beautiful addition to any indoor or outdoor space.
- Convenient Side Pocket:** An integrated side pocket provides a handy spot to store a book, magazine, or remote control.
- Sturdy Construction:** The chair features a durable, zinc-plated steel frame designed for long-lasting use.

2. Specifications

- Maximum Weight Capacity:** 330 lbs (150 kg)
- Seat Size:** 23.6" L x 23.6" W (approx. 60 x 60 cm)
- Seat Back Height:** 14.6" (approx. 37 cm)
- Overall Hanging Height (from tassels to O-ring):** 54.3" (approx. 138 cm)

3. Installation & Hanging Instructions

1. **Choose a Location:** Select a suitable location indoors (e.g., living room, bedroom) or outdoors (e.g., covered patio, balcony). Ensure there is ample space for the chair to swing freely.
2. **Check the Support:** The most critical step is to confirm that your overhead support point (ceiling beam, sturdy tree branch, or stand) is structurally sound and can safely hold well over 330 lbs.
3. **Attach Hanging Hardware:** Use appropriate hardware (e.g., a heavy-duty screw eye bolt, not included) to secure the chair's O-ring to the support point. We recommend consulting a professional if you are unsure about the installation.
4. **Adjust Height:** Ensure the chair is hung at a comfortable height for sitting and standing. The chair should be stable and not twist when empty.

4. How to Use

- Gently sit down in the center of the seat, holding the ropes for balance if needed.
- The chair is designed for relaxed sitting and gentle swinging. Avoid standing on the seat or making sudden, jerky movements.
- Use the side pocket to keep your reading materials or small personal items within easy reach.

5. Care and Maintenance

- **Cleaning the Ropes:** Spot clean the cotton ropes with a mild soap solution and a damp cloth. Allow to air dry completely. Do not machine wash or use harsh chemicals.
- **Cleaning the Frame:** Wipe the metal frame with a soft, dry cloth. If wet, dry it immediately to prevent moisture buildup.
- **Storage:** For long-term storage or during harsh weather, we recommend storing the chair indoors in a dry place.