

installation instructions:

PILASTERS

SAFETY INSTRUCTIONS

Make sure to use the correct tools recommended.

Wear safety goggles.

Follow fixture, power tools, and paint manufacturers' instructions and users manuals.

Use common sense and follow good construction practices.

TOOL & MATERIAL CHECKLIST

- construction adhesive
- caulking gun
- electric drill
- miter saw
- noncorrosive screws

IMPORTANT INFO

- It is highly recommended that you paint or finish pilaster before you install it.
- Once installed, you can apply any necessary touchup paint or finish. Note: A high quality exterior grade latex paint is recommended.
- Place pilaster in room 2 to 3 days prior to installation. This allows the moulding to adjust to the temperature of the room.
- Clean installation surface and back of pilaster of all dirt and dust with a clean cloth or sponge. Make sure that the surface and the back of the moulding are completely dry before attempting installation.

INSTALL INSTRUCTIONS:

1. Measure the distance from the landing floor to the top of the brickmoulding.
2. Cut the pilaster to 3/16" longer than the top of the brickmoulding. Note: always trim from the bottom of the pilaster
3. Apply construction adhesive around the top and side edges of the Pilasters. Do not apply adhesive to the bottom edge. The bottom edge should remain open to allow moisture to seep out.
4. Next, position the Pilasters over moisture resistant house wrap and fasten with noncorrosive fasteners.

Note: If new construction, after installation of the pilasters butt and fit the manufacturer's recommended J-Channel to the sides of the moulding.

EXAMPLE DIAGRAM:

