



Eucatex of North America  
2550 Northwinds Parkway, Suite 235  
Alpharetta, Georgia 30004  
(678)-624-0160  
Fax (678)-624-0621  
www.eucatex.com.br

***This instruction sheet describes the proper methods for installing Eucatex decorative wall paneling.***

***Eucaboard / Euca plac paneling is intended for dry interior use only and requires care in handling. Eucatex prefinished paneling is suitable for normal dry interior use environments. Eucatex prefinished paneling should not be used in environments where an accumulation of grease, smoke, or other surface contaminants will require frequent cleaning to remove accumulations.***

## **HARDBOARD- Eucaboard / Euca plac**



### **Conditioning Panels**

Condition panels by placing them in the room to be paneled 48 hours prior to installation. Stack the panels on the floor or lean them against a wall, with spacers between each sheet. This allows the room air to circulate around each panel for proper acclimation.

### **Wall Preparation**

Installing paneling over existing true walls requires no preliminary preparation. Sanding high spots on the wall is generally about all you have to do. In most homes, studs are spaced 16" on center, but 24" centers and other spacing may exist, especially in exterior walls. Stud spacing must be determined, since paneling must be nailed through the backing into studs or furring 16" on center for maximum holding. Measure stud centers and snap vertical chalk lines along the wall for each stud. If studs are over 16" on center, install horizontal furring 16" on center following recommendations in section 10. If you're paneling over a new wall, check your local building codes to see if you're allowed to install paneling 1/4" and thicker directly to studs without a backing. Paneling thinner than 1/4" will require installation of a noncombustible backer over the studs. Exterior walls must be insulated and have a 4 mil or greater vapor barrier installed on the living side of the wall prior to panel installation.

Hardboard paneling is recommended to always be installed over a solid noncombustible backing such as gypsum wallboard.

### **Arrange Panels**

If you have chosen simulated wood grain panels, take a few minutes to stand the panels side-by-side around the room. Arrange them to achieve the most pleasing balance of color and grain pattern, then number the back of each panel in sequence.

## Cutting Panels



If measured floor-to-ceiling height is 8' or less, subtract  $\frac{1}{2}$ " from this measurement to allow  $\frac{1}{4}$ " expansion clearance on top and bottom. Transfer these measurements to panels for cutting. If using a handsaw or table saw, mark and cut the panels face up. If using a portable circular saw or sabre saw, mark and cut panels face down. Cut-outs for door and window sections, electrical switches and outlets or heat registers require careful measurements.

Many a good paneling job has been ruined by inaccurate cutting for outlet boxes or heat registers. One method is to mark the outlet box with chalk. Then, place the properly cut panel on the wall and tap at the outlet location. This will transfer an image to the back of the panel and indicate the area for cutting. A  $\frac{1}{4}$ " gap around this area will provide room for spacing and adjustment – the faceplate will cover up the extra space. On an existing wall, adjust the outlet box to meet panel thickness. Unscrew at the top and bottom, wedge a small paneling scrap at screw locations, and tighten.

## Spacing Between Panels

A  $\frac{1}{16}$ " gap between adjacent panels is recommended to allow for expansion. Never butt panels tightly. A  $\frac{3}{16}$ " space should be provided around windows and doors.

**DO** leave space between panels - **DON'T** butt panels tightly together **TO AVOID BUCKLED PANEL**

## Fitting Panels



Put the first panel in place and bring to adjacent wall in the corner allowing  $\frac{1}{16}$ " space. Make sure it is plumb and both left and right panel edges fall on solid stud backing. The panel may have to be trimmed to allow the outer edge to fall on the center of a stud for nailing. Also, on rough walls, or adjoining a fireplace wall, use a pencil compass to mark the panel on the inner edge and then cut on the scribe line to fit around the obstruction. Before nailing the paneling, paint a stripe of color to match the paneling groove color on the wall location where the panels will meet.

## Adhesive Application



Adhesive application may be used to apply Hardboard requiring both adhesive and nails.

Adhesive may be used to apply paneling directly to studs or over existing walls as long as the surface is level, sound and clean. Once the panel is fitted, apply beads of adhesive with a caulking gun in a continuous strip along the top, bottom and both sides of the panel. On intermediate studs, apply beads 3' long and 6' apart. Over solid backing, apply adhesive in a zigzag pattern between studs. Some supplemental nailing will be necessary to hold the panel in place until the adhesive sets. Be sure to read the adhesive manufacturer's instructions carefully prior to installation, since instructions may vary. Use a hammer and padded wood block (or rubber mallet) to set the glued panel in position.

## Tub and Shower Installation

In addition to the recommendations in section 7, securely seal all edges and joints with a 100% silicone caulk to prevent water entry.

## Tools and Supplies for Installation

Assemble all your tools and supplies before you begin the job. Here is what you will need for most common wall paneling installations:

Tape measure / level / pencil compass / hammer and nail set / padded wooden block(or rubber mallet)/ power or handsaw (with short fine-toothed blade)/ carpenter's square / chalk line/ drill/ adhesive caulking gun/eye goggles(must be worn when using any power or hand tools) /keyhole saw/ miter box/ mouldings/ base trim/ plane, or wood rasp to dress panel edges/ file (for use with mouldings)/ notched trowel/ hacksaw (for mouldings)/ tub caulk/cloths for clean-up



Eucatex of North America  
2550 Northwinds Parkway, Suite 235  
Alpharetta, Georgia 30004  
(678)-624-0160  
Fax (678)-624-0621  
www.eucatex.com.br

---

## HOW MUCH DO YOU NEED?

1. Measure the perimeter of the room you'd like to panel.

Write down measurement in inches.

Length + Width X 2 = Perimeter

2. Divide that number by 48

Perimeter ÷ 48 =

3. To allow for cutting waste, multiply that number by five percent.

X 0.05 =

4. Add these two numbers together (2 & 3).

This is the total number of panels needed.

+            =            Total number of panels

Note: When using cleaning materials, experiment with scrap paneling or spot clean in an inconspicuous area. Eucatex is not responsible for any damage caused by such cleaning methods.

1/8" and 3/16" HARDBOARD panels should be installed over a suitable noncombustible backing such as gypsum wallboard. Consult your local building codes for approved application. Be sure to read the instructions printed on the back of each panel. Do not install Hardboard or Wood Fiber direct-to-studs in mobile homes.

Consult your local building codes for approved application. Be sure to read the instructions printed on the back of each panel.

Material Safety Data Sheet (MSDS) containing potential physical and health hazard information is available by contacting: Product Safety – [eucatexusa@eucatex.net](mailto:eucatexusa@eucatex.net)

Care should be taken in installing panels to allow for space between panels and heat producing appliances and ignition sources. Consult your local building code authority for guidelines and requirements.

---

<sup>i</sup> Eucatex of North America customer service [eucatexusa@eucatex.net](mailto:eucatexusa@eucatex.net)