

How to brew French press coffee:

Step 1

For each 4-ounce cup, put 1 rounded tablespoon or 1 Bodum scoop of coarse-ground coffee into the pot.

Step 2

Pour hot (not boiling) water into the pot. Leave a minimum of 1 inch of space at the top. Stir with a plastic spoon.

Step 3

Place the plunger unit on top of the pot. Do not press down. Let the coffee brew for 4 minutes.

Step 4

After 4 minutes press down the plunger and enjoy.