

# INSTRUCTION GUIDE

## NO-CALK DRAINS



- 1** Apply a half inch bead of Oatey Plumber's Putty all the way around the underside of the No-Calk barrel flange. *(Note: Putty CANNOT be used on ABS drain assembly.)*
- 2** Place the No-Calk barrel through the top side of the shower base hole.
- 3** Compress the drain down as far as you can without twisting.
- 4** Place the rubber sealing gasket and friction washer over the barrel to the underside of the shower base. *(Note: Rubber gasket is pushed up against the underside of the shower base.)*
- 5** Tighten the locking ring down with adjustable pliers.
- 6** Remove any excess putty from the top of the drain. In colder temperatures, you may need to wait 15 minutes and tighten again to ensure that all excess putty has been forced out from under the flange.
- 7** Install the shower base into the final location.
- 8** Place the rubber pipe gasket over the drainpipe coming up through the No-Calk barrel. Tapered end of the gasket MUST be facing up.
- 9** Push down on the rubber pipe gasket until it sets at the bottom of the No-Calk barrel.
- 10** Thread the gasket. Set screw into place over the drainpipe with the tool provided and tighten with a screwdriver.
- 11** Snap in your drain cover.

