
## **ASSEMBLY INSTRUCTIONS**

# TWIN/FULL L-BUNK BED WITH DESK AND SLIDE



WF289726 / WF289727

### SAFETY WARNINGS AND GENERAL NOTES:

Follow the information on the warnings on the bunk bed end structure and on the carton. Do not remove the warning label from the bed. Always use the recommended size mattress on mattress support, or both, to help prevent the likelihood of entrapment or falls.

The top surface of the mattress must be at least 5\*inch (127mm) below the upper edge of the guardrail.

Do not allow children under 6 years of age to use the upper bunk.

Periodically check and ensure the guardrail, ladder and other components are in their proper position, free from damage, and all connectors are tight.

Do not allow horseplay on or under beds.

Always prohibit jumping on the bed.

Prohibit more than one person on upper bunk.

Always use the ladder for entering and leaving the upper bunk.

Do not use substitute parts. Contact the manufacturer or dealer for replacement parts.

Use of a night-tight may provide added safely precaution for a child using the upper bunk.

Always use guardrails on both long sides of the upper bunk.

If the bunk bed will be placed next to a wall, the guardrail that runs the full length of the bed should be placed against the wall to prevent entrapment between the bed and the wall.

The use of water or sleep flotation mattresses is prohibited.

STRANGULATION HAZARD-Never attach or hang items to any part of the bunk bed that are not designed for use with the bed.

Keep these instructions for future reference.

We recommend assembling your bunk bed on the shipping carton to protect your floor or carpet.

Be certain all staples are out of the box before beginning assembly on the shipping carton.


THIS BED IS DESIGNED TO USE A TWIN MATTRESSES 38 1/2" WIDE X 74"-75" LONG WITH THE TOTAL THICKNESS NOT EXCEEDING 6" FOR UPPER BUNK, FOR THE LOWER FULL-SIZE SHOULD BE 54" WIDE X 74"-75" LONG, WIDE WITH 8" THICKNESS.


SURFACE OF MATTRESS MUST BE AT LEAST 5" (127MM) BELOW THE UPPER EDGE OF GUARDRAILS.

Replacement Parts:

Replacement Parts, including additional guardrails, may be obtained from any of our (GIGACLOUD TECHNOLOGY (USA) INC.) dealers

# **Detail View**





## Hardware List WF289726


	T = 1	T _ T
<b>1</b>		<b>3 9 9 9</b>
Ø8*30mm	(Ø15)1/4"*100mm	(Ø15)1/4"*80mm
Wood dowel (16pcs)	Hex-Head bolts (30pcs)	Hex-Head bolts (52pcs)
4	5	6
(Ø12)1/4"*60mm	(Ø12)1/4"*40mm	1/4"*15 (9.5mm)
Hex-Head bolts (14pcs)	Hex-Head bolts (10pcs)	Horizontal-Hole bolts (96pcs)
		9
(Ø12)1/4"*40mm	(Ø12)1/4"*35mm	(Ø12)1/4"*30mm
Hex-Head bolts (8pcs)	Hex-Head bolts (4pcs)	Hex-Head bolts (14pcs)
10	11 (†) ) ) ) )   (†) ) )   (†) )   (†)   (	12
(1/4")4.5*58mm	Ø4*30mm	Ø9*90mm
Allen key (1pc)	Wood screws (68pcs)	Metal connector (4pcs)
Allen key (1pc)  13	Wood screws (68pcs)	Metal connector (4pcs)
13		15
13	14	15
13 (Ø12)1/4"*50mm	80*28*20*(2mm)	15 142*18*2mm
13  (Ø12)1/4"*50mm  Hex-Head bolts (14pcs)  16  Ø4*19mm	14 80*28*20*(2mm) Hooks (2pcs) 17 Ø10*40mm	142*18*2mm Hooks (2pcs) 18
13  (Ø12)1/4"*50mm  Hex-Head bolts (14pcs)  16  Ø4*19mm  Wood screws (6pcs)	80*28*20*(2mm) Hooks (2pcs)  17  Ø10*40mm Wood dowel (16pcs)	142*18*2mm Hooks (2pcs)
13  (Ø12)1/4"*50mm  Hex-Head bolts (14pcs)  16  Ø4*19mm	14 80*28*20*(2mm) Hooks (2pcs) 17 Ø10*40mm	142*18*2mm Hooks (2pcs) 18
13  (Ø12)1/4"*50mm  Hex-Head bolts (14pcs)  16  Ø4*19mm  Wood screws (6pcs)	14 80*28*20*(2mm) Hooks (2pcs) 17 Ø10*40mm Wood dowel (16pcs) 20	142*18*2mm Hooks (2pcs) 18


## ASSEMBLY TOOLS REQUIRED ( NOT INCLUDED )








PLEASE BE CAREFUL DO NOT DAMAGE THE HOLE POSITION WHEN YOU USE POWER TOOLS!


























Note: Do not lock the screws of the bed slats to the outermost edge of the bed slats, you need to leave a certain space at the edges, otherwise it will cause the board to break. Do not lock the bed slats on the edge of the wood, please hold firmly before screwing, hold it in place with one hand, then lock the screw.

