


Item # : D42CRNMSH

Assembly Instructions




Walker Edison®

Please visit our website for the most current instructions, assembly tips, report damage, or request parts. www.walkeredison.com


Revised 30/04/2019(L)

General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are: wood dowels, screws and bolts.
- V. The provided glue is to secure wood dowels in place. When first inserting dowels, locate the appropriate hole for the dowel, place a small amount of glue in the hole and insert the dowel. Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together, place a small amount of glue on the end of the dowel before attaching parts together. Wipe away excess glue immediately.



- VI. A Phillips head screwdriver is required for the assembly of this product .




- VII. Power tools should not be used to assemble this product.












- VIII. Drill may be needed for securing product to wall.

Parts List



Hardware List


A		Ø1/4"*40mm	Bolt	4 pcs
B		Ø1/4"*25mm	Bolt	5 pcs
C		Ø1/4"*12mm	Bolt	4 pcs
D		Ø1/4"*32mm	Bolt	8 pcs
E		Ø1/4"*22mm	Bolt	2 pcs
F		Ø1/4"*10mm	Bolt	6 pcs
G			Hole cover	1 pc
H		M4	Hex Key	1 pc



Philips head screwdriver required for assembly
(not included)


*The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.*

Step 1




Using bolt (F) secure parts (11,12) to parts (13,14) ,then using bolt (E) attach part (13) to part (14) with hex key (H) as per diagram.

Step 2




Using bolt (C) secure part (6) to parts (4,5,8) ,then using bolt (D) secure part (7) to parts (4,5) with hex key (H) as per diagram.

Step 3




Using bolt (D) secure parts (1,2) to parts (3,4,5,8) with hex key (H) as per diagram.

Step 4




Using bolt (F) secure part (9,10) to parts (1,2) ,then using bolt (D) secure part (10) to part (7) with hex key (H) as per diagram.

Step 5




Using bolt (B) secure parts (6,8) to parts(16,17) with hex key (H) as per diagram.

Step 6




Using bolt (A) secure parts (11,12,13,14) to parts (16,17) with hex key (H) as per diagram.

Step 7



Put hole cover (G) to part (16) and place part (15) to part (14) as per diagram.

Step 8



Final Assembly