


ASSEMBLY INSTRUCTIONS SS16304BK

10'X14' Attached Pergola







Thanks for choosing our product. Please kindly check parts listed below and read this manual carefully, then assemble them step by step. Please feel free to contact us for any questions.




Attention




1. We care about every customer's using experience, please feel free to chat us if has anything missing or damaged or any advice, efficient solution would be offered soon.
2. Recommend 3-4 person to assemble togther.
3. Please use ladder when you install the top.
4. Please keep your children away when you assembly. This item contains small parts which can be swallowed by children.


Parts List

<p>A X2</p>  <p>Top Back Leg</p>	<p>B X3</p>  <p>Top Front Leg</p>	<p>C X5</p>  <p>Bottom Leg</p>	<p>D X4</p>  <p>Side Beam</p>	
<p>D1 X2</p>  <p>Middle Beam</p>	<p>E X16</p>  <p>Board Arm</p>	<p>F X14</p>  <p>Board Protection</p>	<p>G X7</p>  <p>Middle Board Connection</p>	
<p>H X8</p>  <p>Arm Connection</p>	<p>I X2</p>  <p>Arm Hold Tube(Side)</p>	<p>I1 X1</p>  <p>Arm Hold Tube(Middle)</p>	<p>J X2</p>  <p>Arm Hold Tube Connection</p>	
<p>K1 X7</p>  <p>Back UV Protected Board</p>	<p>K2 X7</p>  <p>Front UV Protected Board</p>	<p>L X5</p>  <p>Leg Connection</p>	<p>M X12</p>  <p>Wall & Beam Connection</p>	
<p>N X4</p>  <p>Back Connection</p>	<p>O X2</p>  <p>Right Beam Hold</p>	<p>P X2</p>  <p>Left Beam Hold</p>	<p>Q X16</p>  <p>Arm & Beam Connection</p>	
<p>R X16</p>  <p>Arm Protection</p>	<p>S X8</p>  <p>Arm Up Connection</p>	<p>T X8</p>  <p>Arm Down Connection</p>	<p>U X4</p>  <p>Beam Plug</p>	
<p>V X18</p>  <p>Hold Plug</p>	<p>W X179</p>  <p>Bolt M6*5mm</p>	<p>X X24</p>  <p>Bolt M6*35mm</p>	<p>Y X20</p>  <p>Bolt M6*15mm</p>	
<p>Z1 X32</p>  <p>Bolt M6*40mm</p>	<p>Z2 X10</p>  <p>Bolt M6*70mm</p>	<p>Z3 X1</p>  <p>Allen Wrench</p>	<p>Z4 X1</p>  <p>Middle Wall Connection</p>	<p>Z5 X6</p>  <p>Expansion Bolts</p>



STEP 1



A		X2
B		X3
C		X5
L		X5
W		X40





STEP2





M		X12
Z2		X10
W		X2

STEP3




D		X4
N		X4
W		X32
D1		X2

STEP4





STEP 5

O		X2
P		X2
W		X17
Z4		X1





STEP 6

S		X8
T		X8
Z1		X32
E		X16




STEP 7




Q		X16
X		X16
W		X32
H		X8



STEP8



TIPS: Part Q is used by slotted holes that please use the same sides of both holes to make top side of Q higher than Part D . Slotted holes will support the cover board more strongly.




STEP9



STEP 10




R		X8
W		X8
F		X7



STEP11

G



X7



Up the side with
leaking hole




STEP12

K2  X7




STEP 13



R		X8
W		X8
F		X7



STEP 14






STEP 15



STEP 16

U		X4
V		X18



STEP 17

