


Item # : AF30ZANCT

Assembly Instructions




Walker Edison®

Please visit our website for the most current instructions, assembly tips, report damage, or request parts. www.walkerediton.com


Revised 09/10/2019 (E)

General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are: wood dowels, screws and bolts.
- V. The provided glue is to secure wood dowels in place. When first inserting dowels, locate the appropriate hole for the dowel, place a small amount of glue in the hole and insert the dowel. Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together, place a small amount of glue on the end of the dowel before attaching parts together. Wipe away excess glue immediately.



- VI. A Phillips head screwdriver is required for the assembly of this product.




- VII. Power tools should not be used to assemble this product.













- VIII. Drill may be needed for securing product to wall.

Parts List



Hardware List


A		Ø8x30mm	Wooden dowel	10 pcs
B		Ø15x11mm	Cam lock	4 pcs
C		Ø6x35mm	Cam bolt	4 pcs
D			Sticker	4 pcs
E		M 4	Hex Key	1 pc
F		Ø6x12mm	Bolt	19 pcs
G		Ø6x25mm	Bolt	4 pcs
J		Ø4x38mm	Screw	4 pcs
K			Glue tube	1 pc



Philips head screwdriver required for assembly
(not included)


*The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.*

Step 1




Secure cam bolt (C) into part (1) with Philips head screwdriver as per diagram.

Step 2





Insert wooden dowel (A) into parts (2,3) as per diagram.

Step 3





Using bolt (F) attach part (4) into part (3) with hex key (E) as per diagram.
Note: Do not tighten all bolts .

Step 4




Attach part (3) to part (2) and using bolt (F) secure part (4) into part (2) with hex key (E) as per diagram .

Step 5





Using cam lock (B) attach parts (2,3) into part (1) with Philips head screwdriver as per diagram.

Step 6




Using bolt (F) attach parts (5,7) into part (1) with hex key (E) as per diagram.

Step 7




Using bolt (F) attach part (4) to part (7),part (6) to part (1) with hex key (E)as per diagram .

Step 8




Using bolt (G) attach part (8) into parts (5,6,7) with hex key (E) , then using screw (J) attach part (8) into parts (2,3) with Philips head screwdriver as per diagram.

Step 9




Using bolt (F) attach part (9) into part (8) with hex key (E) as per diagram.
Note: tighten all bolts .

Step 10



Place sticker (D) cover the holes as per diagram.

Step 11



Final Assembly