

# Side-Press Mop Wringer & Bucket Instructions



## INSTRUCTIONS:

1. When unpacking the wringer, press the handle down to release tension on the cable tie then cut the cable tie and release handle slowly.
2. Place the wringer on to the bucket pressing down firmly several times making sure the wringer is securely fastened to the bucket.
3. Fill bucket with desired cleaning solution or water, do not fill more than 2/3 of the bucket to avoid overflowing when mop is placed in to the bucket.
4. Place mop head in bucket with water or cleaning solution and let soak.
5. To wring out the Mop head, place the mop head in the wringer and press the wringer handle down until all liquid is wrung out. Slowly release pressure on the wringing handle until it is in its resting position. **DO NOT RELEASE HANDLE ABRUPTLY AS THIS MAY CAUSE INJURY AS HANDLE IS UNDER TENSION FROM SPRING MECHANISM.**
6. Begin mopping the floor.
7. **DO NOT PLACE HANDS INSIDE WRINGER WHEN OPERATING AS THIS CAN CAUSE INJURY.**
8. **MOP WRINGER & BUCKET IS FOR ADULT USE ONLY!**
9. **WE ARE NOT RESPONSIBLE FOR ANY DAMAGE OR LOSS DUE TO THE MIS-USE OF THIS DEVICE.**
10. **CAUTION; DO NOT LEAVE BUCKET OF WATER UNATTENDED IN THE PRESENCE OF CHILDREN OR BABIES.**
11. **IF YOU HAVE ANY QUESTIONS OR COMMENTS PLEASE FEEL FREE TO CALL US AT (800) 821-6786 OR E-MAIL US AT [CUSTOMERSERVICE@THECLEANSTORE.COM](mailto:CUSTOMERSERVICE@THECLEANSTORE.COM).**