


## PLEASE RETAIN THIS INFORMATION FOR YOUR FUTURE REFERENCE

### OPERATING INSTRUCTION:

- Insert 2 AA batteries (not included) into battery compartment on the back of unit.
- Press the “ON/OFF” button to light up LED, and press it again to turn it off.
- The “TRY-ME” is intended for in-store demonstration only. Please remove “TRY-ME” wire and insert batteries into battery compartment during normal operation.
- Remove battery if product is left unused for a long time.



### BATTERY INSTALLATION:

- Locate battery compartment on the back of unit.
- Remove compartment door.
- Place 2 new AA batteries (batteries not included) into the compartment matching the polarity of the batteries to the markings in the compartment.
- Replace battery compartment door and hold door in place.

### CAUTION:

- Do not mix alkaline, standard (carbon-zinc) or rechargeable (ni-cad, ni-mh, etc.) batteries.
- Do not mix old and new batteries. Replace all batteries of a set at the same time.
- Clean the battery contacts and also those of the device prior to battery installation.
- Ensure the batteries are installed correctly with regard to polarity (+ and -).
- Remove batteries from equipment which is not to be used for an extended period of time.
- Remove used batteries promptly.
- Batteries should only be changed under adult supervision.
- Do not dispose of batteries in fire, batteries may explode or leak.
- Exhausted batteries are to be removed from the product.
- Batteries are harmful if swallowed, so keep away from young children.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Notes: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.