




STRAIGHT TUBE ELBOW ADJUSTMENT


**CAREFUL!!: WEAR GLOVES (RUBBER COATED)
TO AVOID CUTTING HANDS AND PROVIDE GRIP**



STEP 1:


TURN TOP GORE 180 DEGREES
WHILE HOLDING BOTTOM THREE
GORES. THE SEAM SHOULD NOW
BE OPPOSITE FROM THE OTHER
GORES.

TURN TOP GORE 180°



STEP 2:


TURN THE TOP TWO GORES TOGETHER
WHILE HOLDING THE BOTTOM TWO GORES.
THE SEAMS SHOULD BE OPPOSITE.



TURN 2 GORES 180°

STEP 3:

TURN BOTTOM GORE 180 DEGREES, AT
THIS POINT THE ELBOW SHOULD NOW
BE 90 DEGREES, WITH THE SEAMS
ALTERNATING SIDES.



TURN BOTTOM GORE 180°

