







HARDWARE INCLUDED IN THIS KIT:

Item	Qty
1. Standoff.....	5
2. Hex bolt, washer and nut....	4
3. T-Guide.....	1
4. J-Hook / Hanger.....	2
5. End Stop.....	2
6. Anti-jump Disc.....	2
7. Hex Head Lag Bolt and washer.....	5
8. Track - 80".....	1



TOOLS REQUIRED





READ ALL INSTRUCTIONS PRIOR TO STARTING!

BEFORE GETTING STARTED: PRECAUTIONS

1. Please wear safety gear appropriate to the tools being used. Eye protection should be used at all times. Failure to use protective eye gear can result in serious injury. ALWAYS wear proper safety gear when operating power tools.
2. Always ensure you have ample space to operate power tools with complete control of the power tool.
3. Barn Door installation requires the install of anti-jump discs as well as end stops to ensure the door cannot come off the track. Failure to properly install these safety items could cause serious injury or even death. These items are required for safe operation of this Barn Door hardware.
4. The Door(s) are heavy and should be lifted by 2 people at all times. Mishandling of heavy objects (i.e., doors) may cause loss of balance resulting injury. Always take precautions in assuring proper balance before moving the door(s). Safety shoes should also be worn in order to prevent injury.
5. The doors roll on the track which can create pinch points (hair, finger, clothing, etc.).
6. Take care in not catching fingers in door opening when sliding the door closed.




PRIOR TO INSTALLING HARDWARE

1. Ensure door clearances. (figure 1).
2. Install flat, no profile, head casing (not included with barn door hardware kit) securely mounted into the wall studs prior to installing the Barn Door hardware. The head casing should be a minimum of 6¼" tall x ¾" thick x 80" long (figure 2). This piece should be made of hardwood that can withstand 150lbs of weight. **IT IS CRITICAL this piece be secured to the studs and level for proper travel of the doors.**
3. Finish Head Casing prior to starting hardware install.



TRACK INSTALLATION


1. Install track by first measuring / marking hole location on the head of casing (figure 3 & 4).
2. Drill $\frac{3}{16}$ " pilot holes (figure 4).
MAKE SURE hole marks are level before drilling.
3. Using hex head lag bolts (part #7) install track (part #8) between head casing and track (figure 5).



J-HOOK/HANGAR INSTALLATION

1. Install J-hook hangers (part #4) with hex bolt, washer and nuts (part #2) in factory pre-drilled stile holes as shown (figure 6).

*** NOTE:**
To Ensure Proper Alignment And Function.
Tighten Bolts On J-Hook On Last Track AFTER Everything Has Been Levelled



J-HOOK/HANGAR INSTALLATION (continued)

2. Carefully place the door on the track (figure 7)
3. On both ends of the track, install end stops (part #5) approximately 2" from the end of the track to prevent the door from rolling off (figure 8).
4. Prior to installing the anti-jump (part #6), operate the door back and forth carefully to check all clearances.
5. Once clearances and proper door operation are established, install anti-jump discs as shown 6" to 8" from the edge of the door (figure 9).
6. Install T-guide (part #3) on floor. With door hanging vertical (check with level), measure from wall to the middle of the groove in the bottom edge of door. Slide the door carefully (so as to not have the door come off the track) all the way to the other end of the track. Install T-guide. Roll door back to middle (figure 10).
7. Adjust end stops to desired location. **Note: Based on door width used, end stop may be required to slide on track to secure last stand off.**




Figure 7

Figure 8




Figure 9





Figure 10