


A-Frame Climber

USER MANUAL



READ AND SAVE THIS INSTRUCTION FOR FUTURE USE

SAFETY & WARNINGS

ADULT ASSEMBLY REQUIRED.

- Keep these instructions for future reference.
- This product is intended for indoor, outdoor, home, domestic use only. It is not suitable for commercial or medical use.
- The assembly of the product must be done carefully and by an able-bodied adult. If in any doubt, ask a technically qualified person.
- Ensure the installation area is ventilated.
- Do not use the product if it is damaged or defective. If it is damaged or defective, please contact a qualified technician.
- Check that all parts are assembled well and are stable before use. Defective parts must be changed immediately as they can impair the function and the safety of the product.
- Use the product only on even and non-slip surfaces. Keep sufficient space around for safety. Place in a well-lit room.
- Keep away from fire or any source of ignition.
- Packing materials are not toys, keep them away from children.
- Dress children appropriately: do not allow children to wear loose-fitting clothing including ponchos, scarves and garments with drawstrings. Well-fitting shoes must be worn at all times.
- Provide adult supervision at all times.


PLEASE DO NOT RETURN TO STORE




**Please do not return this product to the retailer!!
We are able to assist you in ANY way**

If you find that you have any trouble with assembly or missing or damaged parts please contact the seller.


PART LIST



Upper Climber x 2



Lower Climber x 2




A-Frame Side Panel x 3



Swing Seat x 1




Swing Arm x 2



Swing Armrest x 1



Swing Base x 2




Swing Bar & Beam x 1



Basketball x 1



Basketball Ring x 1



Basketball Net x 1



Clasp x 4



Plastic Screwdriver x 1



Metal Screw A x 2



Screw B x 2



Screw C x 6



Screw D x 7



Screw E x 19



Square Screw F x 3




Screw G x 1




Plug x 2

ASSEMBLY




Step1

Connect the A-Frame Side Panel with 1pc Square Screw F and 1pc Screw E on each set. Repeat the same to complete 3 sets in total.




Step2

Connect the Swing Base to the Side Panel at the bottom, secure with 2pcs Screw D. Slide the Swing Bar through the hole on Side Panel, secure with 1pc Metal Screw A, Screw B, and Screw D.




Step3

Connect the 2 Swing Arms, Seat, and Armrest together, secure with 6pcs Screw C and 1pc Screw G. Attach the Beam on the top of Arms.



Step4


Slide the Swing through the Bar.



Step5


Insert 4 pcs Clasps into the holes on bar to secure the swing in place. Attach the second A-Frame Side Panel, secure the bottom with 2pcs Screw D. Secure the Bar to the Side Panel with Metal Screw A, Screw B, and Screw D.

ASSEMBLY



Step6


Combine the Upper Climber and Lower Climber. No screw needed in this step.




 Screw E x 4

Step7


Connect 1 Climber Panel with the A-Frame Panel, secure with 4pc Screw E.



 Screw E x 4

Step8


Connect the 2nd Climber Panel, secure the with 4pcs Screw E.




 Screw E x 8

Step9

Attach the 3rd A-Frame Side Panel to the Climber assembled, secure with 8pcs Screw D.



 Screw D x 1

Step10

Install the Basketball Hoop on the A-Frame Side Panel, secure with 1pc Screw D.
You can fill the Swing Base with water or sand for added balance, and cover the hole with Plug.