

Installation Instructions

Step 1



Review Installation Checklist

- Do not push parts into track until ready to install in final position.
- Do not remove from track once installed.
- Use a new saw blade for best cutting results.
- Depending on molding type, all parts may NOT be used.
- Always install screws in end holes of track and then every other hole.
- For concrete floors, drill hole using 3/16" (5mm) diameter drill, insert plastic anchor, then use screw.
- Attach the track directly to the subfloor (remove any padding or underlayment).
- Laminate flooring installations require the use of T-Moldings in doorways 4 feet (1.22 meters) or less and in rooms 40 feet (12.2 meters) or larger in length or width.

Step 2

Choose Your Transition Type

Kit allows assembly of four different molding options from one single product.




- A. T-Molding – transitions between equal height hard flooring surfaces.
- B. Carpet Transition – transitions from flooring to carpet.
- C. Hard Surface Reducer – transitions flooring to a lower surface (vinyl, wood, etc.)
- D. End Molding – finishes flooring at sliding doors, fireplaces and other fixed edges.

Step 3

Install Your Moldings


Detailed installation instructions on back

Each individual package includes:



*(Use when installing on concrete subfloors)

Accommodates 7mm to 15mm Floor Thickness



Total Height = Plank + Underlayment

9/32" to 15/32" (7mm to 12 mm)

Track only

15/32" to 9/16" (12mm to 14mm)

Track plus snap on plastic shim

9/16" to 19/32" (14mm to 15mm)

Track over reversed plastic shim

A: T-Molding

Use Part #1

1. Leave a 1-1/8" (29mm) space between flooring as shown.
2. Install track in position with screws as shown. Leave 1/4" (6mm) expansion space on both sides of track.
3. Start at one end. Firmly push Part #1 down into track.
4. Continue to push down firmly into track, working from one end to the other.

B: Carpet Transition

Use Part #1 and Part #2

1. Leave a 1-3/8" (35 mm) space between laminate flooring and vertical edge as shown.
2. Install track in position with screws as shown. Leave 1/2" (12mm) expansion space between the track and laminate flooring.
3. Hold Part #1 and Part #2 together as shown.
4. Start at one end and push down firmly into track while holding Part #1 and Part #2 together.
5. Continue to push down firmly into track, working from one end to the other.

C: Hard Surface Reducer

Use Part #1 and Part #3

1. Leave a 1-3/8" (35mm) space between laminate flooring and hard surface as shown.
2. Install track in position with screws as shown. Leave 1/2" (12mm) expansion space between the track and laminate flooring.
3. Hold Part #1 and Part #3 together as shown.
4. Start at one end and push down firmly into track while holding Part #1 and Part #3 together.
5. Continue to push down firmly into track, working from one end to the other.

D: End Molding

Use Part #1 and Part #2

1. Leave a 1-3/8" (35 mm) space between laminate flooring and vertical edge as shown.
2. Install track in position with screws as shown. Leave 1/2" (12mm) expansion space between the track and laminate flooring.
3. Hold Part #1 and Part #2 together as shown.
4. Start at one end and push down firmly into track while holding Part #1 and Part #2 together.
5. Continue to push down firmly into track, working from one end to the other.
6. Fill any space between end molding and vertical surface with 100% silicone sealant.

