


LEARNING ABOUT YOUR RICE COOKER

Product may vary slightly from what is illustrated.



1. Cool Touch Knob
2. Tempered Glass Lid with Steam Vent
3. Steam Basket **(If applicable)**
4. Cooking Bowl with Water Level Markings
5. Cool Touch Handle
6. Cooker
7. Orange Indicator Light (WARM)
8. Red Indicator Light (COOK)
9. ON Switch

10. Measuring Cup

11. Serving Spoon

-----Page break-----

BEFORE FIRST USE

- Remove all packing material and stickers from the product and save instruction manual.

Caution: Tear up all plastic bags as they can pose a risk to children.

- Cut and remove tie wrap located between the electric plug blades.
- Remove the cooking bowl, lid and steam basket (if applicable) from rice cooker.
- Wash cooking bowl, lid, steam basket (if applicable), serving spoon and measuring cup with warm sudsy water. Rinse and dry thoroughly before returning to cooker.
- Wipe the body with a damp cloth, dry thoroughly.

HOW TO USE YOUR RICE COOKER

When the appliance is operating for the first time, there may be a slight burning odor, as the heating elements warm up. This represents no danger to the user and does not indicate a defect in the appliance. Allow the appliance to heat up until the odor clears.

To Cook Rice:

- Place appliance on a flat stable surface.

Caution: Because some countertop finishes are more sensitive than others, use care not to place appliance on surfaces where heat may cause damage.

Note: Do not place the rice cooker directly underneath your cabinets or too close to a wall.

- Using the measuring cup provided, measure out the desired amount of rice to make. Use the rice cooking chart provided in this manual as reference.
- Place rice in the cooking bowl.

Note: For softer rice, allow rice to soak for 10 – 20 minutes before cooking.

- Using the measuring cup provided or the water level markings located inside the cooking bowl, add the appropriate amount of water. Refer to the **rice cooking chart**.

Note: Be careful not to add too much water as it may cause the unit to boil over.

- Add butter, oil and/or seasonings as desired.
- Before placing the cooking bowl into the cooker, make sure the heating plate and outside surface of the cooking bowl are clean and dry.
- Insert cooking bowl into the cooker.

Note: Do not let loose rice or particles fall into the cooker.

- Cover unit with glass lid.