

DuroStar DSTP15-AC 120V Fuel Transfer Pump

1. Connect all parts correctly and ensure they are sealed properly



2. Connect the power and turn on the motor.



3. Place the nozzle in the fuel tank to be filled and grip the handle.
4. Release the handle when you are finished fueling.

Attention:



1. Zero the meter before and after use.
2. DO not overpower the motor.
3. Wash the filter regularly.



Application

DuroStar Fuel/Oil Pumps are intended for pumping Diesel, Kerosene, or other fuel oil, for vehicle, storage, construction, farm, and outdoor Equipment.

This pump kit contains: Motor, Pump, Flow Meter, and dial. Featuring convenience, reliability, easy operation, and simple maintenance. The clear easy-to-read display can be used for either single use measurements, or accumulated pumping data.

Note: Non-Commercial Use Only

Technical Specifications:

Model: DSTP15-AC

Pump Flowrate: 5.25 – 15.85 GPM

Meter Flowrate: 5.25 – 31.70 GPM

Voltage: 120v +/- 10% (60 Hz)

Max Pressure: 43.5 PSI

Motor: .55 Kw @ 1400 rpm

Display: 4 Digit, Max 9999.9

