

Quick Setup Guide

Wi-Fi IP Camera



STOP: Only install a camera in its final location AFTER it's paired, and setup is completed.

Flexible Setup Options:

Option 1:

Add on Camera - Connecting to your Night Owl Wi-Fi NVR (WNVR):

- Run the WNVR's Startup Wizard and follow the onscreen instructions.
- When prompted, plug in the camera(s) no more than 8 ft. from the WNVR.

NOTE: Camera is only compatible as an add on for the WNIP2 Series Wi-Fi NVR.



Option 1 Setup Video

Option 2:

Standalone Camera - Connecting to your Wi-Fi Router:

First Time User? Download Night Owl Protect. Create an account and log in with your username and password. Already have an account? Log in with your username and password!







2 Tap the "Add New" button, and the app will guide you through the setup process.



Option 2 Setup Video

Product images in setup videos may vary by model, but the setup is the same.



Why Call? Our Support Site Has it All!

For system manuals, troubleshooting guides, FAQs, video tutorials and more:

- Please visit Support.NightOwlSP.com
- Enter WNIP2-CM into the Search bar.







For more Support Videos, go to www.youtube.com/nightowlsp

FCC RADIATION NORM

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Compliance Statement These limits are designed to provide reasonable protection against frequency interference in residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed or used in accordance with the instructions, may cause harmful interference to radio communication. However, there is no guarantee that interference will not occur in television reception, which can be determined by turning the equipment off and on. The user is encouraged to try and correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

- · Increase the separation between the equipment and the receiver.
- · Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.
CAUTION!

The Federal Communications Commission warns the user that changes or modifications to the unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

This equipment should be installed and operated with a minimum distance of 8 inches between the radiator and your body.

REV 3-200922