


内页1

INSTRUCTIONS

1

Antenna Assembling

Attach the bracket to the antenna unit using the screw and wing nut provided.



1

2

Installation


2.1 Mast Mounting

Install a mast (not provided) on the house, preferably on the side of the house facing the TV station transmitters. Attach the antenna to the mast using the U-bolt and two wing nuts provided, and adjust the antenna facing to the TV station transmitters.

2.2 Wall Mounting

Determine the location on the wall where the antenna is to be mounted, preferably on the side of the house facing the TV station transmitters. Attach the antenna to the house using two self-tapping screws (not provided).

内页2



2.1

2.2

3

Connecting

Attach coaxial cable to connector in the antenna. Connect other end of the coaxial cable to the short coaxial cable from power inserter. Attach the long coaxial cable from power inserter to the ANTENNA/CABLE IN connector on the back of the TV or converter box. Connect the power adapter to the DC socket in power inserter. The antenna must be powered in order to function.


4

Setting and Scanning


In the TV's setup menu, set the mode to "Antenna" or "Air", then, set TV to "Scan" for channels. Consult the TV manual for detailed instructions.

内页3

INSTRUCTIONS



3




The **Power Inserter** must be powered in order to function. Push the smart switch On or Off and select the switching with which more channels are received.

· Switch Off - The LED indicates yellow for normal reception.

· Switch On - The LED indicates green for stronger reception.

⚠ Scan channels after each switching in the Power Inserter.



4

5

Adjusting Instruction


For best reception, through screw A, adjust the antenna up and down until get the best reception.

6

Locating

A higher location for antenna mounting towards the broadcast tower may result in better reception.

内页4



6

Note:

- Keep the antenna away from sources of interference including air conditioners, power stations, etc.
- Install the antenna as high as possible, and preferably with a clear path between the antenna and the TV station transmitters. Trees, buildings, mountains, etc., can all impact the performance of any antenna.

封底

We want to satisfy our customers 100% with their purchase, but we do have some policies in place.

Warranty Policy

Manufacturer, Antop Antenna Inc., warrants its products for a period of one year from the date of original purchase. The warranty is valid only with original proof of purchase of the product. This warranty does not apply to any defects or failures of product caused by neglect, misuse, negligence, accident, abuse, mishandling, misapplication, alteration, modification, power outage, unauthorized/unreasonable use, or any uncontrollable environmental damage.

Return Refund Policy

Note: Standard 30-day money back and/or refunds to USA only. Returned merchandise must have RMA number on box and one copy of proof of purchased inside package. RMA number will be obtained in advance from Antop Antenna customer service representative returns department. A stocking fee of 15% can be deducted from a refund ask representative for further details.

Absolutely no refund after 30 days of purchase. For any return for refund, customers should contact their place of purchase to find out the retailer's return policy.

Exchange Replacement Service Agreement

Standard 1 year limited Manufactory warranty on Replacements of a product for exchange due to malfunction, failure or defected, part(s), missing components exchanges will be for the same item, model, Sku, within the 1 year purchased date. No upgrades or exchanges for a different Model/Sku please send us an email at service@antopantenna.com or contact our representatives for trouble-shooting for RMA number email rma@antopantenna.com to receive a replacement or refund. When shipping an item back, you should consider using a traceable shipping service such as tracking number or purchasing shipping insurance especially for higher ticketed items. Exchanged products must be sent to: 2313 E Philadelphia St. STE L Ontario CA 91761 and must contain an RMA number and copy of proof of purchase.

For more information: 1(909) 947-8883 M - F from 9:00 AM to 5:30 PM (PST)

www.antopantenna.com


ANTOP ANTENNA INC | Tel. 1-909-947-8883 | Email: service@antopantenna.com

封面

ANTOP®

AMPLIFIED INDOOR/
OUTDOOR TV ANTENNA

Flat-panel



AT-413B