





























CROSLEY

F U R N I T U R E












Kitchen Island CF3045



PART LIST


A 	B 	C 	D 	E 
Top Panel 1 PC	Bottom Panel 1 PC	Left Panel 1 PC	Right Panel 1 PC	Upper Partition Panel 1 PC
F 	G 	H 	I 	J 
Left Partition Panel 1 PC	Right Partition Panel 1 PC	Left Door 1 PC	Right Door 1 PC	Adjustable Shelf 2 PCS
K 	L 	M 	N 	O 
Front Rail 1 PC	Back Rail 1 PC	Upper Rail 1 PC	Lower Rail 1 PC	Upper Drawer Front Panel 2 PCS
P 	Q 	R 	S 	T 
Upper Drawer Left Panel 2 PCS	Upper Drawer Right Panel 2 PCS	Upper Drawer Back Panel 2 PCS	Upper Drawer Bottom Panel 2 PCS	Lower Drawer Front Panel 2 PCS
U 	V 	W 	X 	Y 
Lower Drawer Left Panel 2 PCS	Lower Drawer Right Panel 2 PCS	Lower Drawer Back Panel 2 PCS	Lower Drawer Bottom Panel 2 PCS	Upper Back Panel 1 PC
Z 	ZA 			
Lower Side Back Panel 2 PCS	Lower Middle Back Panel 1 PC			

HARDWARE LIST

<div>#1</div>  <div>Ø1/4"*22mm</div>	<div>#2</div>  <div>Ø8*30mm</div>	<div>#3</div>  <div>Ø4*25mm</div>	<div>#4</div>  <div>L350mm</div>	<div>#5</div>  <div>φ25mm</div>
<div>Bolt 34 PCS (Extra 1)</div>	<div>Wood Dowel 24 PCS (Extra 1)</div>	<div>Long Screw 32 PCS (Extra1)</div>	<div>Towel Bar 2 PCS</div>	<div>Knob 8 PCS</div>
<div>#6</div>  <div>L50mm*32mm</div>	<div>#7</div>  <div>Ø5/32*18mm</div>	<div>#8</div> 	<div>#9</div>  <div>Ø3*16mm</div>	<div>#10</div> 
<div>Washer 12 PCS</div>	<div>Round Head Bolt 8 PCS (Extra 1)</div>	<div>Magnet 2 PCS</div>	<div>Short Screw 4 PCS (Extra 1)</div>	<div>Shelf Holder 8 PCS (Extra 1)</div>
<div>#11</div>  <div>Allen Wrench 1 PC</div>				

ADDITIONAL TOOLS (Not Provided)


Note: It is not recommended to use power tools during assembly.




Phillips Head Screwdriver

Note: Wood dowels are intended for alignment. Additional clearance between wood dowel and pre-drilled hole is intentional for ease of assembly.


Step 1. Attach knobs (part #5) and washers (part #6) to drawer front panels (parts O & T) and doors (parts H & I) using round head bolts (part #7) and phillips head screwdriver.




Step 2. Attach towel bars (part #4) and washers (part #6) to panels (parts C & D) using bolts (part #1) and allen wrench (part #11).




Step 3. Attach upper drawer panels (parts P & Q) to upper drawer back panel (part R) using long screws (part #3) and phillips head screwdriver. Slide upper drawer bottom panel (part S) to assembled unit (parts P, Q & R). Attach upper drawer front panel (part O) to assembled unit (parts P, Q & S) using long screws (part #3) and phillips head screwdriver. Repeat for remaining drawer.



Step 4. Attach lower drawer panels (parts U & V) to lower drawer back panel (part W) using long screws (part #3) and phillips head screwdriver. Slide lower drawer bottom panel (part X) to assembled unit (parts U, V & W). Attach lower drawer front panel (part T) to assembled unit (parts U, V & X) using long screws (part #3) and phillips head screwdriver. Repeat for remaining drawer.







Step 5. Attach magnets (part #8) to front rail (part K) using short screws (part #9) and phillips head screwdriver.




- | | | |
|----|---|-----|
| #8 |  | x 2 |
| #9 |  | x 4 |

Step 6. Attach upper rail (part M) to top panel (part A) using bolts (part #1), wood dowels (part #2) and allen wrench (part #11).




- | | | |
|-----|---|-----|
| #1 |  | x 4 |
| #2 |  | x 2 |
| #11 |  | x 1 |


Step 7. Attach partition panels (parts F & G) to lower rail (part N) using bolts (part #1), wood dowels (part #2) and allen wrench (part #11).




Step 8. Attach bottom panel (part B) to assembled unit (parts F & G) using bolts (part #1), wood dowels (part #2) and allen wrench (part #11).




Step 9. Attach panels (parts C & D) to bottom panel (part B) using bolts (part #1), wood dowels (part #2) and allen wrench (part #11).






Step 10. Carefully turn the assembled parts upright. Slide back panels (parts Z & ZA) to assembled unit (parts B, C, D, F & G).







Step 11. Attach rails (parts K & L) to assembled unit (parts C, D, F & G) using bolts (part #1), wood dowels (part #2) and allen wrench (part #11).
Note: Ensure back panels (parts Z & ZA) are fully inserted into back rail (part L) with no gaps.




- | | | |
|-----|---|-----|
| #1 |  | x 8 |
| #2 |  | x 4 |
| #11 |  | x 1 |

Step 12. Attach upper partition panel (part E) to assembled unit (parts K & L) using bolts (part #1), wood dowels (part #2) and allen wrench (part #11).




- | | | |
|-----|---|-----|
| #1 |  | x2 |
| #2 |  | x2 |
| #11 |  | x 1 |


Step 13. Slide upper back panel (part Y) to assembled unit (parts C, D & L).



Step 14. Attach top panel (part A) to assembled unit (parts C, D, E & Y) using bolts (part #1), wood dowels (part #2) and allen wrench (part #11).




Step 15. Place shelf holders (part #10) into desired position and slide adjustable shelves (part J) into place.



Step 16. Slide assembled drawers into place.

Note: To release trigger disconnect levers push one side up and the other down.



Step 17. Attach doors (parts H & I) by placing bottom pin hinge (pre-installed in door) in the pre-drilled hole of bottom panel (part B). Then depress the top spring-loaded pin hinge so it can be placed in the pre-drilled hole of front rail (part K).

Note: Be sure top and bottom pin hinges are fully extended to secure door in place.

Note: It is important to adjust levelers once fully assembled and upright. Extend adjustable leveler until it's firmly in contact with the floor. If relocating, adjust leveler as needed until it's firmly in contact with the floor in new location.

