


# HOME DECORATORS COLLECTION

SK19148A ABERDEEN HALL TREE 76"Hx47-3/4"Wx15-3/4"D

INV#99500













## ASSEMBLY INSTRUCTIONS

Made In China




Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment. Count all parts and material hardware, then compare with parts list to be sure all parts are present. If any parts are missing or damaged, please contact our Customer Service Department for efficient and speedy service. Please indicate the model number and code letter of part(s) needed.

**IMPORTANT NOTE:** Follow instructions listed below in proper sequence as numbered to assure fast, easy and correct assembly.


PARTS LIST		
<b>A</b>  TOP PANEL-1PC	<b>B</b>  TOP SIDE PANEL-2PCS	<b>D</b>  TOP PARTITION-2PCS
<b>E</b>  TOP BACK PANEL-1PC	<b>F</b>  TOP FIXED PANEL-1PC	<b>G</b>  BOTTOM FIXED PANEL-1PC
<b>H</b>  LEFT MIDDLE BACK PANEL-1PC	<b>I</b>  RIGHT MIDDLE BACK PANEL-1PC	<b>J</b>  MIDDLE SIDE PANEL-2PCS
<b>K</b>  BOTTOM LFET SIDE PANEL-1PC	<b>L</b>  BOTTOM RIGHT SIDE PANEL-1PC	<b>M</b>  BOTTOM PANEL-1PC

N




FRONT CROSS BRACE-2PCS

O




BOTTOM BACK PANEL-1PC

P




BOTTOM PARTITION -1PC

Q




DRAWER FRONT PANEL-4PCS

R




DRAWER BACK PANEL-4PCS

S




DRAWER LEFT  
SIDE PANEL-4PCS

T




DRAWER RIGHT  
SIDE PANEL-4PCS

U




DRAWER  
BOTTOM PANEL-4PCS

V



CUSHION-1PC

W





















MIDDLE FOOT-1PC

X




FOOT-4PCS

<p><b>a</b></p>  <p>WOOD DOWEL-78PCS</p>	<p><b>b</b></p>  <p>CAM LOCK BOLT-46PCS</p>	<p><b>c</b></p>  <p>CAM LOCK-52PCS</p>
<p><b>d</b></p>  <p>SHORT PLASTIC COVER-8PCS</p>	<p><b>f</b></p>  <p>LONG PLASTIC COVER-8PCS</p>	<p><b>g</b></p>  <p>5/8"L ROUND HEAD SCREW-6PCS</p>
<p><b>h</b></p>  <p>1"L FLAT HEAD SCREW-32PCS</p>	<p><b>i</b></p>  <p>POTHOOK-4PCS</p>	<p><b>j</b></p>  <p>LONG BOLT-8PCS</p>
<p><b>k</b></p>  <p>SHORT BOLT-4PCS</p>	<p><b>l</b></p>  <p>HANDLE-4PCS</p>	<p><b>m</b></p>  <p>LONG CAM LOCK BOLT-3PCS</p>
<p><b>n</b></p>  <p>1-1/2"L FLAT HEAD SCREW-4PCS</p>		
<div> <div>  <p><b>1</b></p> <p>x4 RECTANGLE METAL PLATE</p> </div> <div>  <p><b>2</b></p> <p>x2 1/2"L FLAT HEAD SCREW</p> </div> <div>  <p><b>3</b></p> <p>x2 PLASTIC ANCHOR</p> </div> <div>  <p><b>4</b></p> <p>x2 PLASTIC BAND</p> </div> <div>  <p><b>5</b></p> <p>x2 1-1/2"L FLAT HEAD SCREW</p> </div> </div> <p>ANTI-TIPPING HARDWARE PACKAGE</p>		



NOTE:THE SURFACE WITH THE STICKER IS THE BACK SIDE

## HOW TO SEPARATE GLIDES





PRIOR TO ASSEMBLY, WE SUGGEST SEPARATING THE INNER GLIDES FROM THE OUTER-GLIDES, SIMPLY PULL THE LEFT/RIGHT INNER GLIDES FROM THE OUTER GLIDES EXPOSING A SMALL BLACK SAFETY RELEASE TAB, BY PUSHING THE SAFETY RELEASE TAB. YOU WILL BE ABLE TO SEPARATE THE GLIDES.

NOTE: • UPON OPENING, THOROUGHLY CLEAN ALL WOOD SURFACES TO REMOVE DUST AND DIRT THAT MAY HAVE SETTLED ONTO THE FINISH DURING SHIPMENT. IN ORDER TO PREVENT DAMAGE DURING ASSEMBLY. PLEASE ASSEMBLE THIS ITEM WITH AT LEAST TWO PEOPLE.




NOTE: TURN THE CAM-BOLT SCREWS UNTIL THEY ARE TIGHT, THE SHOULDER SHOULD BE AGAINST THE SURFACE OF THE PART.

## HOW TO USE THE CAM-TOOL




NOTE: • THE ARROWS ON THE HIDDEN CAM-LOCKS SHOULD POINT TO THE CAM-BOLTS.

# FIG 1



- INSTALL THE WOOD DOWEL (a) INTO THE FOOT (X).
- JOIN THE FOOT (X) TO THE BOTTOM PANEL (M) BY USING THE WOOD DOWEL (a).
- TIGHTEN THE FOOT (X) BY USING THE 1-1/2" L FLAT HEAD SCREW (n).
- TIGHTEN THE MIDDLE FOOT (W) TO THE BOTTOM PANEL (M) AS SHOWN .
- INSTALL THE WOOD DOWEL (a) AND THE CAM LOCK BOLT (b) INTO THE BOTTOM PARTITION (P), THE BOTTOM LEFT SIDE PANEL (K) AND THE BOTTOM RIGHT SIDE PANEL (L).
- JOIN THE FRONT CROSS BRACE (N) TO THE BOTTOM PARTITION (P) AND THE BOTH BOTTOM SIDE PANELS (K) & (L) BY USING THE WOOD DOWEL (a) FIRST.
- TIGHTEN CAM LOCK BOLT (b) WITH THE CAM LOCK (c) IN THE PRE-DRILLED HOLES.


# FIG 2



- INSTALL THE WOOD DOWEL (a) AND THE CAM LOCK BOLT (b) INTO THE BOTTOM PANEL (M).
- JOIN THE ASSEMBLED PART TO THE BOTTOM PANEL (M) BY USING THE WOOD DOWEL (a) FIRST.
- TIGHTEN CAM LOCK BOLT (b) WITH THE CAM LOCK (c) IN THE PRE-DRILLED HOLES.
- SLIDE THE BOTTOM BACK PANEL (O) INTO THE GROOVES ON THE BOTTOM LEFT SIDE PANEL (K) AND THE BOTTOM RIGHT SIDE PANEL (L).




# FIG 3




- INSTALL THE WOOD DOWEL (a) AND THE CAM LOCK BOLT (b) INTO THE BOTTOM OF THE BOTTOM FIXED PANEL (G) AS SHOWN.
- JOIN THE BOTTOM FIXED PANEL (G) TO THE ASSEMBLED PART BY USING THE WOOD DOWEL (a) FIRST.
- TIGHTEN CAM LOCK BOLT (b) WITH THE CAM LOCK (c) IN THE PRE-DRILLED HOLES.

# FIG 4




- TIGHTEN THE BOTTOM BACK PANEL (O) BY USING THE 5/8"L ROUND HEAD SCREW (g).

# FIG 5




- ATTACH THE POTHOOK (i) TO THE LEFT MIDDLE BACK PANEL (H) AND THE RIGHT MIDDLE BACK PANEL (I) BY USING THE SHORT BOLT (k) AS SHOWN.

# FIG 6




- INSTALL THE WOOD DOWEL (a) AND THE CAM LOCK BOLT (b) INTO TWO MIDDLE SIDE PANELS (J).
- JOIN TWO MIDDLE SIDE PANELS (J) TO THE LEFT MIDDLE BACK PANEL (H) AND THE RIGHT MIDDLE BACK PANEL (I) BY USING THE WOOD DOWEL (a) FIRST.
- TIGHTEN CAM LOCK BOLT (b) WITH THE CAM LOCK (c) IN THE PRE-DRILLED HOLES.

# FIG 7




- JOIN THE LEFT MIDDLE BACK PANEL (H) TO THE RIGHT MIDDLE BACK PANEL (I) BY THE LONG CAM LOCK BOLT (m) AND THE WOOD DOWEL (a) FIRST.
- TIGHTEN LONG CAM LOCK BOLT (m) WITH THE CAM LOCK (c) IN THE PRE-DRILLED HOLES.

# FIG 8




- INSTALL THE WOOD DOWEL (a) AND THE CAM LOCK BOLT (b) INTO THE TOP OF THE BOTTOM FIXED PANEL (G) AS SHOWN.
- JOIN TWO ASSEMBLED PARTS BY USING THE WOOD DOWEL (a) FIRST.
- TIGHTEN CAM LOCK BOLT (b) WITH THE CAM LOCK (c) IN THE PRE-DRILLED HOLES.
- COVER CAM HOLES WITH THE LONG PLASTIC COVER (f).

# FIG 9



- INSTALL THE WOOD DOWEL (a) INTO TWO TOP SIDE PANELS (B) AND TWO TOP PARTITIONS (D) AS SHOWN.
- JOIN TWO TOP SIDE PANELS (B) AND TWO TOP PARTITIONS (D) TO THE TOP FIXED PANEL (F) BY USING THE WOOD DOWEL (a) FIRST.
- TIGHTEN THE TOP FIXED PANEL (F) BY USING THE 1" L FLAT HEAD SCREW (h) THROUGH THE PRE-DRILLED HOLES ON THE BOTTOM OF THE TOP FIXED PANEL (F) AS SHOWN.
- SLIDE THE TOP BACK PANEL (E) INTO THE GROOVES ON TWO TOP SIDE PANELS (B).


# FIG 10



- INSTALL THE WOOD DOWEL (a) INTO THE TOP PANEL (A) AS SHOWN.
- JOIN THE TOP PANEL (A) TO THE ASSEMBLED PART BY USING THE WOOD DOWEL (a) FIRST.
- TIGHTEN THE TOP PANEL (A) BY USING THE 1"L FLAT HEAD SCREW (h) THROUGH THE PRE-DRILLED HOLES ON THE TOP OF THE TOP PANEL (A) AS SHOWN.
- TIGHTEN THE TOP BACK PANEL (E) BY USING THE 5/8"L ROUND HEAD SCREW (g).




# FIG 11




- INSTALL THE WOOD DOWEL (a) AND THE CAM LOCK BOLT (b) INTO THE BOTTOM OF THE TOP FIXED PANEL (F) AS SHOWN.
- JOIN TWO ASSEMBLED PARTS BY USING THE WOOD DOWEL (a) FIRST.
- TIGHTEN CAM LOCK BOLT (b) WITH THE CAM LOCK (c) IN THE PRE-DRILLED HOLES.
- COVER CAM HOLES WITH THE LONG PLASTIC COVER (f).

# FIG 12




- INSTALL THE WOOD DOWEL (a) AND THE CAM LOCK BOLT (b) INTO THE DRAWER FRONT PANEL (Q).
- JOIN THE DRAWER LEFT SIDE PANEL (S) AND THE DRAWER RIGHT SIDE PANEL (T) TO THE DRAWER FRONT PANEL (Q).
- ONCE JOINED, TIGHTEN CAM LOCK BOLT (b) WITH THE CAM LOCK (c) IN THE PRE-DRILLED HOLES.
- COVER CAM HOLES WITH THE SHORT PLASTIC COVER (d).
- SLIDE THE DRAWER BOTTOM PANEL (U) INTO THE GROOVES ON THE DRAWER LEFT SIDE PANEL (S) AND THE DRAWER RIGHT SIDE PANEL (T).
- JOIN THE DRAWER BACK PANEL (R) TO THE ASSEMBLED DRAWER PART AND TIGHTEN THE DRAWER BACK PANEL (R) BY USING THE 1" L FLAT HEAD SCREW (h) THROUGH PRE-DRILLED HOLES ON DRAWER SIDE PANELS.
- TIGHTEN THE DRAWER HANDLE (i) TO THE DRAWER FRONT PANEL (Q) BY USING THE LONG BOLT (j).

# FIG 13




- INSERT DRAWERS INTO THE ASSEMBLED PART.
- PLACE THE CUSHION (V) ABOVE THE BOTTOM FIXED PANEL (G).

# FIG 14



- TIGHTEN THE RECTANGLE METAL PLATE (1) TO THE REAR OF THE TOP PANEL (A) BY USING 1/2" FLAT HEAD SCREW (2).
- PLACE THE ASSEMBLED ABERDEEN HALL TREE AT THE DESIRED POSITION. MARK THE INSERTION POINTS FOR THE PLASTIC ANCHOR (3).
- USING THE PROPER HARDWARE FOR YOUR WALL TYPE, DRILL 1/4" HOLES INTO THE WALL.
- TIGHTEN THE RECTANGLE METAL PLATE (1) TO THE PLASTIC ANCHOR (3) BY USING THE 1-1/2" FLAT HEAD SCREW (5).

# FIG 15



- USING THE PLASTIC BAND (4) CONNECT TWO RECTANGLE METAL PLATES (1).