


# HOME DECORATORS COLLECTION

1002949621 1002949622 1002949623  
1002960603 1002960604 1002960605

SK19081CR2 SADIE DOUBLE HALL TREE WITH CUSHION 76"Hx47.75"Wx15.75"D













## ASSEMBLY INSTRUCTIONS


Made In China






Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment. Count all parts and material hardware, then compare with parts list to be sure all parts are present, If any parts are missing or damaged, phone, fax, or mail to our Customer service Department for efficient and speedy service. Please indicate the model number and code letter of part(s) needed.

**IMPORTANT NOTE:** Follow instructions listed below in proper sequence as numbered to assure fast,easy and correct assembly.


PARTS LIST		
<b>A</b>  TOP PANEL-1PC	<b>B</b>  TOP LEFT SIDE PANEL-1PC	<b>C</b>  TOP RIGHT SIDE PANEL1PC
<b>D</b>  TOP PARTITION-2PCS	<b>E</b>  TOP CROSS BRACE-1PC	<b>F</b>  TOP FIXED PANEL-1PC
<b>G</b>  TOP DECORATION-2PCS	<b>H</b>  TOP BACK PANEL-1PC	<b>I</b>  MIDDLE BACK PANEL-2PCS
<b>J</b>  LEFT BACK FRAME-1PC	<b>K</b>  RIGHT BACK FRAME-1PC	<b>L</b>  MIDDLE BACK FRAME-1PC

**M**


MIDDLE FIXED PANEL-1PC

**N**BOTTOM  
LEFT SIDE PANEL-1PC**O**BOTTOM  
RIGHT SIDE PANEL-1PC**P**


MIDDLE PARTITION-1PC

**Q**


BOTTOM FIXED PANEL-1PC

**R**


BOTTOM PANEL-1PC

**S**


ADJUSTABLE SHELF-2PCS

**T**


LEFT DOOR-2PCS

**U**






RIGHT DOOR-2PCS

**V**


BOTTOM BACK PANEL-1PC

**W**


DRAWER FRONT PANEL-2PCS

**X**DRAWER  
LEFT SIDE PANEL-2PCS**Y**DRAWER  
RIGHT SIDE PANEL-2PCS**Z**DRAWER  
BACK PANEL-2PCS**AA**DRAWER  
BOTTOM PANEL-2PCS**BB**

CUSHION-1PC


























**CC**

BOTTOM DECORATION-2PCS

**DD**


BOTTOM PARTITION-1PC

NOTE:THE SURFACE WITH THE STICKER IS THE BACK SIDE

<div>a</div> <div></div> <div>WOOD DOWEL-72PCS</div>	<div>b</div> <div></div> <div>CAM LOCK BOLT-46PCS</div>	<div>c</div> <div></div> <div>CAM LOCK-46PCS</div>	
<div>d</div> <div></div> <div>PLASTIC COVER-24PCS</div>	<div>e</div> <div></div> <div>Ø1/4"X1-1/4"L BOLT-16PCS</div>	<div>f</div> <div></div> <div>5/8" L ROUND HEAD SCREW-54PCS</div>	
<div>g</div> <div></div> <div>POTHOOK-4PCS</div>	<div>h</div> <div></div> <div>Ø5/32"X10mm POTHOOK BOLT-4PCS</div>	<div>i</div> <div></div> <div>DRAWER HANDLE-2PCS</div>	
<div>j</div> <div></div> <div>Ø5/32"X5/8" L DRAWER HANDLE BOLT-4PCS</div>	<div>k</div> <div></div> <div>1-1/4" L FLAT HEAD SCREW-8PCS</div>	<div>l</div> <div></div> <div>1" L FLAT HEAD SCREW-20PCS</div>	
<div>m</div> <div></div> <div>KNOB-4PCS</div>	<div>n</div> <div></div> <div>Ø5/32"X7/8" L KNOB BOLT-4PCS</div>	<div>o</div> <div></div> <div>METAL PLATE-2PCS</div>	
<div>p</div> <div></div> <div>SHELF PIN-8PCS</div>	<div>q</div> <div></div> <div>1" L BOLT-16PCS</div>	<div>r</div> <div></div> <div>1/2" L FLAT HEAD SCREW-16PCS</div>	<div>s</div> <div></div> <div>MAGNET-2PCS</div>
<div>t</div> <div></div> <div>ALLEN WRENCH-1PC</div>	<div><div><div>1</div><div></div><div>x4 RECTANGLE METAL PLATE</div></div><div><div>2</div><div></div><div>x2 1/2" L FLAT HEAD SCREW</div></div><div><div>3</div><div></div><div>x2 PLASTIC ANCHOR</div></div><div><div>4</div><div></div><div>x2 PLASTIC BAND</div></div><div><div>5</div><div></div><div>x2 1-1/2" L FLAT HEAD SCREW</div></div></div> <div>ANTI-TIPPING HARDWARE PACKAGE</div>		



NOTE:THE SURFACE WITH THE STICKER IS THE BACK SIDE

## HOW TO SEPARATE GLIDES






PRIOR TO ASSEMBLY, WE SUGGEST SEPARATING THE INNER GLIDES FROM THE OUTER-GLIDES, SIMPLY PULL THE LEFT/RIGHT INNER GLIDES FROM THE OUTER GLIDES EXPOSING A SMALL BLACK SAFETY RELEASE TAB, BY PUSHING THE SAFETY RELEASE TAB. YOU WILL BE ABLE TO SEPARATE THE GLIDES.

NOTE: • UPON OPENING, THOROUGHLY CLEAN ALL WOOD SURFACES TO REMOVE DUST AND DIRT THAT MAY HAVE SETTLED ONTO THE FINISH DURING SHIPMENT. IN ORDER TO PREVENT DAMAGE DURING ASSEMBLY. PLEASE ASSEMBLE THIS ITEM WITH AT LEAST TWO PEOPLE.




NOTE: TURN THE CAM-BOLT SCREWS UNTIL THEY ARE TIGHT, THE SHOULDER SHOULD BE AGAINST THE SURFACE OF THE PART.

## HOW TO USE THE CAM-TOOL




NOTE: • THE ARROWS ON THE HIDDEN CAM-LOCKS SHOULD POINT TO THE CAM-BOLTS.

# FIG 1




- TIGHTEN THE POTHOOK (g) ONTO THE MIDDLE BACK PANEL (I) BY USING THE Ø5/32"X10mm POTHOOK BOLT (h) AS SHOWN.
- INSTALL THE WOOD DOWEL (a) AND THE CAM LOCK BOLT (b) INTO THE MIDDLE BACK PANEL (I).
- JOIN BOTH MIDDLE BACK PANELS (I) TO THE MIDDLE BACK FRAME (L) BY USING THE WOOD DOWEL (a) FIRST.
- TIGHTEN CAM LOCK BOLT (b) WITH THE CAM LOCK (c) IN THE PRE-DRILLED HOLES.

# FIG 2




- INSTALL THE WOOD DOWEL (a) AND THE CAM LOCK BOLT (b) INTO THE LEFT BACK FRAME (J) AND THE RIGHT BACK FRAME (K).
- JOIN THE LEFT BACK FRAME (J) AND THE RIGHT BACK FRAME (K) TO THE ASSEMBLED PART BY USING THE WOOD DOWEL (a) FIRST.
- TIGHTEN CAM LOCK BOLT (b) WITH THE CAM LOCK (c) IN THE PRE-DRILLED HOLES.

# FIG 3




- JOIN THE TOP DECORATION (G) AND THE BOTTOM DECORATION (CC) TO THE ASSEMBLED PART BY USING THE WOOD DOWEL (a) FIRST.
- TIGHTEN THE 1-1/4"L BOLT (e) WITH THE ALLEN WRENCH (t) AS SHOWN.

# FIG 4




- INSTALL THE WOOD DOWEL (a) INTO THE TOP OF THE MIDDLE FIXED PANEL (M).
- JOIN THE MIDDLE FIXED PANEL (M) TO THE ASSEMBLED PART BY USING THE WOOD DOWEL (a) FIRST.
- TIGHTEN THE MIDDLE FIXED PANEL (M) BY USING THE 1-1/4"L BOLT (e) WITH THE ALLEN WRENCH (t) AS SHOWN.
- TIGHTEN THE MIDDLE FIXED PANEL (M) BY USING THE 1-1/4"L FLAT HEAD SCREW (k) THROUGH THE PRE-DRILLED HOLES AS SHOWN.

# FIG 5




- INSTALL THE WOOD DOWEL (a) INTO THE BOTTOM OF THE TOP FIXED PANEL (F).
- JOIN THE TOP FIXED PANEL (F) TO THE ASSEMBLED PART BY USING THE WOOD DOWEL (a) FIRST.
- TIGHTEN THE TOP FIXED PANEL (F) BY USING THE 1-1/4\"L BOLT (e) WITH THE ALLEN WRENCH (t) AS SHOWN.
- TIGHTEN THE TOP FIXED PANEL (F) BY USING THE 1-1/4\"L FLAT HEAD SCREW (k) THROUGH THE PRE-DRILLED HOLES AS SHOWN.

# FIG 6




- INSTALL THE WOOD DOWEL (a) INTO THE TOP CROSS BRACE (E).
- JOIN THE TOP CROSS BRACE (E) TO THE TOP LEFT SIDE PANEL (B) AND THE TOP RIGHT SIDE PANEL (C) BY USING THE WOOD DOWEL (a) FIRST.
- INSTALL THE WOOD DOWEL (a) AND THE CAM LOCK BOLT (b) INTO THE BOTTOM OF THE TOP PANEL (A).
- JOIN THE TOP PARTITION (D) AND THE ASSEMBLED PART TO THE TOP PANEL (A) BY USING THE WOOD DOWEL (a) FIRST.
- TIGHTEN CAM LOCK BOLT (b) WITH THE CAM LOCK (c) IN THE PRE-DRILLED HOLES.
- TIGHTEN THE TOP CROSS BRACE (E) BY USING THE 1" L FLAT HEAD SCREW (I) THROUGH THE PRE-DRILLED HOLES AS SHOWN.
- COVER THE CAM HOLES WITH THE PLASTIC COVER (d).

# FIG 7




- INSTALL THE WOOD DOWEL (a) AND THE CAM LOCK BOLT (b) INTO THE TOP OF THE TOP FIXED PANEL (F).
- JOIN TWO ASSEMBLED PARTS BY USING THE WOOD DOWEL (a) FIRST.
- TIGHTEN CAM LOCK BOLT (b) WITH THE CAM LOCK (c) IN THE PRE-DRILLED HOLES.
- COVER THE CAM HOLES WITH THE PLASTIC COVER (d).

# FIG 8




- TIGHTEN THE MAGNET (s) ONTO THE BOTTOM FIXED PANEL (Q) BY USING THE 5/8" L ROUND HEAD SCREW (f).
- INSTALL THE WOOD DOWEL (a) INTO THE TOP OF THE BOTTOM FIXED PANEL (Q).
- JOIN THE MIDDLE PARTITION (P) TO THE BOTTOM FIXED PANEL (Q) BY USING THE WOOD DOWEL (a) FIRST.
- TIGHTEN THE MIDDLE PARTITION (P) BY USING THE 1" L FLAT HEAD SCREW (I) THROUGH THE PRE-DRILLED HOLES AS SHOWN.

# FIG 9




- INSTALL THE WOOD DOWEL (a) AND THE CAM LOCK BOLT (b) INTO THE BOTTOM OF THE BOTTOM FIXED PANEL (Q).
- JOIN THE BOTTOM PARTITION (DD) TO THE ASSEMBLED PART BY USING THE WOOD DOWEL (a) FIRST.
- TIGHTEN CAM LOCK BOLT (b) WITH THE CAM LOCK (c) IN THE PRE-DRILLED HOLES.
- COVER CAM HOLES WITH THE PLASTIC COVER (d).

# FIG 10




- INSTALL THE WOOD DOWEL (a) AND THE CAM LOCK BOLT (b) INTO THE BOTTOM LEFT SIDE PANEL (N) AND THE BOTTOM RIGHT SIDE PANEL (O).
- JOIN BOTH BOTTOM SIDE PANELS (N) & (O) TO THE ASSEMBLED PART BY USING THE WOOD DOWEL (a) FIRST.
- TIGHTEN CAM LOCK BOLT (b) WITH THE CAM LOCK (c) IN THE PRE-DRILLED HOLES.

# FIG 11




- INSTALL THE WOOD DOWEL (a) AND THE CAM LOCK BOLT (b) INTO THE BOTTOM PANEL (R).
- JOIN THE BOTTOM PANEL (R) TO THE ASSEMBLED PART BY USING THE WOOD DOWEL (a) FIRST.
- TIGHTEN CAM LOCK BOLT (b) WITH THE CAM LOCK (c) IN THE PRE-DRILLED HOLES.
- COVER CAM HOLES WITH THE PLASTIC COVER (d).

# FIG 12




- INSTALL THE WOOD DOWEL (a) AND THE CAM LOCK BOLT (b) INTO THE BOTTOM OF THE MIDDLE FIXED PANEL (M).
- JOIN TWO ASSEMBLED PARTS BY USING THE WOOD DOWEL (a) FIRST.
- TIGHTEN CAM LOCK BOLT (b) WITH THE CAM LOCK (c) IN THE PRE-DRILLED HOLES.

# FIG 13



- TIGHTEN THE TOP BACK PANEL (H) AND THE BOTTOM BACK PANEL (V) BY USING THE 5/8"L ROUND HEAD SCREW (f).
- ATTACH THE METAL PLATE (o) TO THE ASSEMBLED PART BY USING THE 1"L BOLT (q), TIGHTEN THE 1"L BOLT (q) WITH THE ALLEN WRENCH (t) AS SHOWN.


# FIG 14



2x


- TIGHTEN THE DRAWER LEFT SIDE PANEL (X) AND THE DRAWER RIGHT SIDE PANEL (Y) TO THE DRAWER FRONT PANEL (W) BY USING THE 1" FLAT HEAD SCREW (I).
- SLIDE THE DRAWER BOTTOM PANEL (AA) INTO THE GROOVES ON THE DRAWER LEFT SIDE PANEL (X) AND THE DRAWER RIGHT SIDE PANEL (Y).
- TIGHTEN THE DRAWER BACK PANEL (Z) TO THE ASSEMBLED PART BY USING THE 1" FLAT HEAD SCREW (I).
- TIGHTEN THE DRAWER HANDLE (i) TO THE DRAWER FRONT PANEL (W) BY USING THE Ø5/32" x 5/8" L BOLT (j).

FIG 15




- INSERT DRAWERS INTO THE ASSEMBLED PART.

FIG 16




- INSERT THE SHELF PIN (p) INTO THE DESIRED POSITION AND PLACE THE ADJUSTABLE SHELF (S) ABOVE THE SHELF PIN (p).

FIG 17




- TIGHTEN THE KNOB (m) ONTO THE LEFT DOOR (T) AND THE RIGHT DOOR (U) BY USING THE  $\varnothing 5/32'' \times 7/8''$  L KNOB BOLT (n).
- ATTACH THE LEFT DOOR (T) AND THE RIGHT DOOR (U) TO THE ASSEMBLED PART BY USING THE  $1/2''$  L FLAT HEAD SCREW (r).

# FIG 18




- ATTACH THE LEFT DOOR (T) AND THE RIGHT DOOR (U) TO THE ASSEMBLED PART BY USING THE 1/2" L FLAT HEAD SCREW (r).
- PLACE THE CUSHION (BB) ABOVE THE MIDDLE FIXED PANEL (M).

# FIG 19



- TIGHTEN THE RECTANGLE METAL PLATE (1) TO THE REAR OF THE TOP PANEL (A) BY USING 1/2" FLAT HEAD SCREW (2).
- PLACE THE ASSEMBLED SADIE DOUBLE HALL TREE AT THE DESIRED POSITION. MARK THE INSERTION POINTS FOR THE PLASTIC ANCHOR (3).
- USING THE PROPER HARDWARE FOR YOUR WALL TYPE, DRILL 1/4" HOLES INTO THE WALL.
- TIGHTEN THE RECTANGLE METAL PLATE (1) TO THE PLASTIC ANCHOR (3) BY USING THE 1-1/2" FLAT HEAD SCREW (5).

# FIG 20



- USING THE PLASTIC BAND (4) CONNECT TWO RECTANGLE METAL PLATES (1).