



## FASTENER & WOOD PEG INSTALLATION

### **Step 1: Gather Tools and Materials**

- Measuring Tape
- Pen/Pencil
- Hacksaw
- Hammer
- \* If installing on a concrete subfloor you'll need a drill with a 3/8" bit and Wood Pegs.

### **Step 2: Measure and Mark the Installation Area**

- Use a measuring tape to determine the exact length of the transition needed.
- If necessary, cut the transition to the required length.
- Place the transition in its intended position and mark the fastener hole locations on the subfloor.

### **Step 3: Prepare the Floor for Installation**

- If the floor is concrete or another hard material, drill pilot holes at the marked spots. Use a drill bit suitable for the flooring material.
- For wooden floors, pre-drilling small pilot holes is optional but can prevent splitting.

### **Step 4: Secure the Transition**

- Align the transition over the pre-drilled holes or marks.
- Insert screw nails through the pre-drilled holes.
- Hammer the screw nails into the floor. Ensure the strip is snug against the floor but not overly tight to allow for expansion.