

## How To Replace Screening

### Tools & Materials Required:

- Screening at least 2" (5 cm) wider than screen frame
- New spline
- Screen tool
- Utility knife
- Screwdriver



**1. Lay screening over frame on flat surface, overlapping spline groove at least 1" on all four sides.**



**2. A: For aluminum screen: use the convex end of screen tool to gently roll screening into the frame groove to crimp screening.**



**B: Using concave end of screen tool, insert spline at one corner and roll into groove over screening. Place hand on screen surface to hold screen straight. Roll spline into groove on all four sides.**



**3. Trim off excess screening with utility knife on outside edge of the spline groove.**

## Choose the Right Screen for the Job

Saint-Gobain ADFORS offers a variety of specialty screen types to meet any need.



### Clear Advantage

Nearly invisible screen allows more light and enhances curb appeal



### Extra Strength

Extend the life of your screen in high traffic areas



### Pet Resistant

Withstands damage from household pets



### Small Insect

Greater protection from tiny insects



### Sun Guard

Controls the damaging effects of the sun

### Also Available

- Standard Aluminum
- Standard Fiberglass

Visit [www.adfors.com](http://www.adfors.com) to learn more about our products, view our how-to videos and use our screen selector tool to make sure you have the right screen for your needs.

Follow us on:



Ortho-Phthalate free 

