


HOME DECORATORS COLLECTION

SK18903R1 SHELTON STORAGE LOCKER 78"Hx56.1"Wx16.6"D

INV#96086













ASSEMBLY INSTRUCTIONS

Made In China




Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment. Count all parts and material hardware, then compare with parts list to be sure all parts are present. If any parts are missing or damaged, phone, fax, or mail to our Customer Service Department for efficient and speedy service. Please indicate the model number and code letter of part(s) needed.

IMPORTANT NOTE: Follow instructions listed below in proper sequence as numbered to assure fast, easy and correct assembly.


PARTS LIST		
A 	B 	C 
TOP PANEL-1PC	TOP LEFT SIDE PANEL-1PC	TOP RIGHT SIDE PANEL-1PC
D 	E 	F 
BACK SIDE CROSS BRACE-2PCS	BACK MIDDLE CROSS BRACE-1PC	TOP PARTITION-2PCS
G 	H 	I 
SIDE ADJUSTABLE SHELF-4PCS	MIDDLE ADJUSTABLE SHELF-2PCS	FRONT TOP CROSS BRACE-1PC
J 	K 	L 
TOP FIXED PANEL-1PC	MIDDLE PARTITION-2PCS	BOTTOM FIXED PANEL-1PC

M




DOOR-3PCS

N




BOTTOM LEFT SIDE
PANEL-1PC

O




BOTTOM RIGHT SIDE
PANEL-1PC

P




BOTTOM PARTITION-2PCS

Q




FRONT BOTTOM CROSS
BRACE-1PC

R




BOTTOM PANEL-1PC

S




DRAWER FRONT PANEL-3PCS

T




DRAWER LEFT SIDE
PANEL-3PCS

U




DRAWER RIGHT SIDE
PANEL-3PCS

V




DRAWER BACK PANEL-3PCS

W




DRAWER BOTTOM
PANEL-3PCS

X




TOP SIDE BACK PANEL-2PCS

Y


































TOP MIDDLE BACK
PANEL-1PC

Z




BOTTOM BACK PANEL-1PC

NOTE:THE SURFACE WITH THE STICKER IS THE BACK SIDE

<p>a</p>  <p>WOOD DOWEL-76PCS</p>	<p>b</p>  <p>CAM LOCK BOLT-56PCS</p>	<p>c</p>  <p>CAM LOCK-56PCS</p>					
<p>d</p>  <p>LONG PLASTIC COVER-28PCS</p>	<p>e</p>  <p>POTHOOK-6PCS</p>	<p>f</p>  <p>1/2"L FLAT HEAD SCREW-30PCS</p>					
<p>g</p>  <p>1"L FLAT HEAD SCREW-18PCS</p>	<p>h</p>  <p>5/8"L ROUND HEAD SCREW-78PCS</p>	<p>i</p>  <p>METAL PLATE-12PCS</p>					
<p>j</p>  <p>SHORT BOLT-6PCS</p>	<p>k</p>  <p>HANDLE-3PC</p>	<p>l</p>  <p>KNOB-3PCS</p>					
<p>m</p>  <p>SHELF PIN-24PCS</p>	<p>n</p>  <p>MAGNET-3PCS</p>	<p>o</p>  <p>SHORT PLASTIC COVER-12PCS</p>					
<p>p</p>  <p>LONG BOLT-3PCS</p>	<table border="1"> <tr> <td data-bbox="598 1736 726 1937"> <p>1</p>  <p>x4 RECTANGLE METAL PLATE</p> </td> <td data-bbox="742 1736 869 1937"> <p>2</p>  <p>x2 1/2"L FLAT HEAD SCREW</p> </td> <td data-bbox="885 1736 1013 1937"> <p>3</p>  <p>x2 PLASTIC ANCHOR</p> </td> <td data-bbox="1029 1736 1157 1937"> <p>4</p>  <p>x2 PLASTIC BAND</p> </td> <td data-bbox="1173 1736 1300 1937"> <p>5</p>  <p>x2 1-1/2"L FLAT HEAD SCREW</p> </td> </tr> </table>		<p>1</p>  <p>x4 RECTANGLE METAL PLATE</p>	<p>2</p>  <p>x2 1/2"L FLAT HEAD SCREW</p>	<p>3</p>  <p>x2 PLASTIC ANCHOR</p>	<p>4</p>  <p>x2 PLASTIC BAND</p>	<p>5</p>  <p>x2 1-1/2"L FLAT HEAD SCREW</p>
<p>1</p>  <p>x4 RECTANGLE METAL PLATE</p>	<p>2</p>  <p>x2 1/2"L FLAT HEAD SCREW</p>	<p>3</p>  <p>x2 PLASTIC ANCHOR</p>	<p>4</p>  <p>x2 PLASTIC BAND</p>	<p>5</p>  <p>x2 1-1/2"L FLAT HEAD SCREW</p>			


NOTE:THE SURFACE WITH THE STICKER IS THE BACK SIDE

HOW TO SEPARATE GLIDES




PRIOR TO ASSEMBLY, WE SUGGEST SEPARATING THE INNER GLIDES FROM THE OUTER-GLIDES, SIMPLY PULL THE LEFT/RIGHT INNER GLIDES FROM THE OUTER GLIDES EXPOSING A SMALL BLACK SAFETY RELEASE TAB, BY PUSHING THE SAFETY RELEASE TAB. YOU WILL BE ABLE TO SEPARATE THE GLIDES.

NOTE: • UPON OPENING, THOROUGHLY CLEAN ALL WOOD SURFACES TO REMOVE DUST AND DIRT THAT MAY HAVE SETTLED ONTO THE FINISH DURING SHIPMENT. IN ORDER TO PREVENT DAMAGE DURING ASSEMBLY. PLEASE ASSEMBLE THIS ITEM WITH AT LEAST TWO PEOPLE.




NOTE: TURN THE CAM-BOLT SCREWS UNTIL THEY ARE TIGHT, THE SHOULDER SHOULD BE AGAINST THE SURFACE OF THE PART.

HOW TO USE THE CAM-TOOL




NOTE: • THE ARROWS ON THE HIDDEN CAM-LOCKS SHOULD POINT TO THE CAM-BOLTS.

FIG 1




- ATTACH THE MAGNETS (h) ONTO THE BOTTOM OF THE TOP FIXED PANEL (J) BY USING 5/8" L ROUND HEAD SCREW (h) THROUGH PRE-DRILLED HOLES.
- INSTALL THE WOOD DOWEL (a) AND THE CAM LOCK BOLT (b) INTO THE TOP OF THE TOP FIXED PANEL (J).
- JOIN THE TOP PARTITION (F) TO THE TOP FIXED PANEL (J) BY USING THE WOOD DOWEL (a) FIRST.
- TIGHTEN CAM LOCK BOLT (b) WITH THE CAM LOCK (c) IN THE PRE-DRILLED HOLES.
- COVER CAM HOLES WITH THE LONG PLASTIC COVER (d).

FIG 2




- ATTACH THE POTHOOKS (e) ONTO THE BACK MIDDLE CROSS BRACE (E) BY USING THE 1/2" FLAT HEAD SCREW (f) THROUGH PRE-DRILLED HOLES.
- INSTALL THE WOOD DOWEL (a) INTO THE BACK MIDDLE CROSS BRACE (E).
- JOIN THE BACK MIDDLE CROSS BRACE (E) TO THE MIDDLE PARTITION (K) BY USING THE WOOD DOWEL (a).

FIG 3




- INSTALL THE WOOD DOWEL (a) AND THE CAM LOCK BOLT (b) INTO BOTTOM OF THE TOP FIXED PANEL (J).
- JOIN TWO ASSEMBLED PARTS BY USING WOOD DOWEL (a) FIRST.
- TIGHTEN CAM LOCK BOLT (b) WITH THE CAM LOCK (c) IN THE PRE-DRILLED HOLES.
- COVER CAM HOLES WITH THE LONG PLASTIC COVER (d).

FIG 4




- ATTACH THE POTHOOKS (e) ONTO THE BACK SIDE CROSS BRACES (D) BY USING THE 1/2" FLAT HEAD SCREW (f) THROUGH PRE-DRILLED HOLES.
- INSTALL THE WOOD DOWEL (a) INTO THE FRONT TOP CROSS BRACE (I).
- INSTALL THE WOOD DOWEL (a) AND THE CAM LOCK BOLT (b) INTO THE TOP LEFT SIDE PANEL (B) AND THE TOP RIGHT SIDE PANEL (C).
- JOIN THE BOTH TOP SIDE PANELS (B) & (C) TO THE ASSEMBLED PART AND THE FRONT TOP CROSS BRACE (I) BY USING WOOD DOWEL (a) FIRST.
- TIGHTEN CAM LOCK BOLT (b) WITH THE CAM LOCK (c) IN THE PRE-DRILLED HOLES.
- COVER CAM HOLES WITH THE LONG PLASTIC COVER (d).

FIG 5




- INSTALL THE WOOD DOWEL (a) AND THE CAM LOCK BOLT (b) INTO THE BOTTOM OF THE TOP PANEL(A).
- JOIN THE TOP PANEL (A) TO THE ASSEMBLED PART BY USING WOOD DOWEL (a) FIRST.
- TIGHTEN CAM LOCK BOLT (b) WITH THE CAM LOCK (c) IN THE PRE-DRILLED HOLES.
- COVER CAM HOLES WITH THE LONG PLASTIC COVER (d).
- TIGHTEN THE FRONT TOP CROSS BRACE (I) TO THE ASSEMBLED PART BY USING THE 1" L FLAT HEAD SCREW (g) THROUGH PRE-DRILLED HOLES AS SHOWN.

FIG 6




- INSTALL THE WOOD DOWEL (a) AND THE CAM LOCK BOLT (b) INTO THE TOP OF THE BOTTOM PANEL(R).
- JOIN THE BOTTOM PARTITION (P) TO THE BOTTOM PANEL (R) BY USING WOOD DOWEL (a) FIRST.
- TIGHTEN CAM LOCK BOLT (b) WITH THE CAM LOCK (c) IN THE PRE-DRILLED HOLES.

FIG 7




- INSTALL THE WOOD DOWEL (a) INTO THE FRONT BOTTOM CROSS BRACE (Q).
- JOIN THE BOTTOM LEFT SIDE PANEL (N) AND THE BOTTOM RIGHT SIDE PANEL (O) TO THE FRONT BOTTOM CROSS BRACE (Q) BY USING WOOD DOWEL (a) FIRST.
- INSTALL THE WOOD DOWEL (a) AND THE CAM LOCK BOLT (b) INTO THE TOP OF THE BOTTOM PANEL(R).
- JOIN TWO ASSEMBLED PARTS BY USING WOOD DOWEL (a) FIRST.
- TIGHTEN CAM LOCK BOLT (b) WITH THE CAM LOCK (c) IN THE PRE-DRILLED HOLES.

FIG 8




- INSTALL THE WOOD DOWEL (a) AND THE CAM LOCK BOLT (b) INTO THE BOTTOM OF THE BOTTOM FIXED PANEL(L).
- JOIN THE BOTTOM FIXED PANEL (L) TO THE ASSEMBLED PART BY USING WOOD DOWEL (a) FIRST.
- TIGHTEN CAM LOCK BOLT (b) WITH THE CAM LOCK (c) IN THE PRE-DRILLED HOLES.
- TIGHTEN THE FRONT BOTTOM CROSS BRACE (Q) TO THE ASSEMBLED PART BY USING THE 1" L FLAT HEAD SCREW (g) THROUGH PRE-DRILLED HOLES AS SHOWN.

FIG 9




- INSTALL THE WOOD DOWEL (a) AND THE CAM LOCK BOLT (b) INTO THE TOP OF THE BOTTOM FIXED PANEL (L).
- JOIN TWO ASSEMBLED PARTS BY USING THE WOOD DOWEL (a) FIRST.
- TIGHTEN THE CAM LOCK BOLT (b) BY USING THE CAM LOCK (c) IN PRE-DRILLED HOLES.
- COVER THE CAM HOLES WITH THE LONG PLASTIC COVER (d).

FIG 10




- TIGHTEN THE TOP SIDE BACK PANEL (X) AND THE TOP MIDDLE BACK PANEL (Y) BY USING THE 5/8" L ROUND HEAD SCREW (h) AND THE METAL PLATE (i) AS SHOWN.
- TIGHTEN THE BOTTOM BACK PANEL (Z) BY USING THE 5/8" L ROUND HEAD SCREW (h).

FIG 11




- INSERT THE SHELF PIN (m) IN THE DESIRED POSITION AND PLACE THE SIDE ADJUSTABLE SHELF (G) AND THE MIDDLE ADJUSTABLE SHELF (H) ON THE PINS AS SHOWN.

FIG 12




- ATTACH THE DOOR (M) TO THE ASSEMBLED PART BY USING THE 1/2" L FLAT HEAD SCREW (f) AS SHOWN.
- TIGHTEN THE KNOB (l) ONTO THE DOOR (M) BY USING THE LONG BOLT (p).

FIG 13




- INSTALL THE WOOD DOWEL (a) AND THE CAM LOCK BOLT (b) INTO THE DRAWER FRONT PANEL (S).
- JOIN THE DRAWER LEFT SIDE PANEL (T) AND THE DRAWER RIGHT SIDE PANEL (U) TO THE DRAWER FRONT PANEL (S) BY USING WOOD DOWEL (a) FIRST.
- TIGHTEN THE CAM LOCK BOLT (b) BY USING THE CAM LOCK (c) IN PRE-DRILLED HOLES.
- COVER CAM HOLES WITH THE SHORT PLASTIC COVER (o).
- SLIDE THE DRAWER BOTTOM PANEL (W) INTO THE GROOVES ON THE DRAWER LEFT SIDE PANEL (T) AND THE DRAWER RIGHT SIDE PANEL (U).
- JOIN THE DRAWER BACK PANEL (V) TO THE ASSEMBLED DRAWER PART AND TIGHTEN THE DRAWER BACK PANEL (V) BY USING THE 1" FLAT HEAD SCREW (g) THROUGH PRE-DRILLED HOLES ON DRAWER SIDE PANELS.
- TIGHTEN THE HANDLE (k) TO THE DRAWER FRONT PANEL (S) BY USING THE SHORT BOLT (j).
- REPEAT STEPS ABOVE FOR THE OTHER DRAWERS.

FIG 14




- INSERT ASSEMBLED DRAWERS TO THE ASSEMBLED PART AS SHOWN.

FIG 15



- TIGHTEN THE RECTANGLE METAL PLATE (1) TO THE REAR OF THE TOP PANEL (A) BY USING 1/2" FLAT HEAD SCREW (2).
- PLACE THE ASSEMBLED SHELTON STORAGE LOCKER AT THE DESIRED POSITION. MARK THE INSERTION POINTS FOR THE PLASTIC ANCHOR (3).
- USING THE PROPER HARDWARE FOR YOUR WALL TYPE, DRILL 1/4" HOLES INTO THE WALL.
- TIGHTEN THE RECTANGLE METAL PLATE (1) TO THE PLASTIC ANCHOR (3) BY USING THE 1-1/2" FLAT HEAD SCREW (5).

FIG 16



- USING THE PLASTIC BAND (4) CONNECT TWO RECTANGLE METAL PLATES (1).