

Instructions for Gate Opener Two Button Entry Transmitter

The two button transmitter is used for the remote control of two gate openers or a gate opener and a garage door opener. A GTO Universal Receiver (RB709U-NB) is required for use with garage door openers.

You can have as many transmitters as you want for family and guests to open your gate. The DIP switches in all the transmitters for a particular gate opener must be set the same.


Instructions for adding additional entry transmitter(s) _


If you already have a two button transmitter that operates your gate(s) and are simply adding an additional transmitter, set the DIP switches in the new transmitter to match the DIP switches in your original transmitter, reassemble the transmitters and you are done.

IMPORTANT:

If you change the DIP switches in the original transmitter refer to **Program**New Transmitter Setting to Gate

Opener's Memory section below.







If you are matching your two button transmitter to a single button transmitter follow these steps:

- Match the eight DIP switches found in the dual button transmitter to the first eight DIP switches in the single button transmitter.
- 2. The ninth DIP switch on the single button transmitter cannot be in the lowest position (-); it must be changed to the upper (+) or middle (0) position at this time.
- 3. If the ninth DIP switch is set to the upper position (+) the top button will be used to send the same code when using the dual button remote.

button remote.



- 4. If the ninth DIP switch is set to the middle position (0) the bottom button will be used to send the same code when using the dual
- If you change the ninth DIP switch in the original transmitter refer to Program New Transmitter Setting to Gate Opener's Memory section below.



FCC Regulation: This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communication communication.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
 Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Connect the equipment into an outlet on a circuit different from th
 Consult the dealer or an experienced radio/TV technician for help.

Instructions for Gate Opener **Two Button Entry Transmitter**

The two button transmitter is used for the remote control of two gate openers or a gate opener and a garage door opener. A GTO Universal Receiver (RB709U-NB) is required for use with garage door openers.

Instructions for replacing a lost entry transmitter _

If you are replacing a lost transmitter and you know or have your original transmitter's DIP switch setting written down, set the new transmitter DIP switches to that setting and it is ready to activate your gate opener.


If you don't know the DIP switch setting from your original transmitter, you will need to select a new setting.


Personalize your Transmitter Setting

There are eight (8) DIP switches, each of which can be placed in three different positions (+,0,-). DO NOT set all switches in the same position, such as all +, all -, or all zeros.


Program New Transmitter Setting to Gate Opener's Memory


Some gate openers are programmed with a LEARN REMOTE or LEARN TRANSMITTER button and some with the ON/OFF switch. Refer to your Gate Opener's or Universal Receiver's Installation Manual for instructions on how to program the transmitter to that device.











ONE YEAR LIMITED WARRANTY

ise, provided the recommended installation procedures have been followed. To a variety state accessory is warrantee by the manufacturer against exercise in materias and manufacturer workmansamp for a period or fore (1) year from and or Junezaes, provisous time, consumences installation procedures have been followed.

GTO Access Systems, LLC (GTO) selfs its products through unbitnered relatal and on-line channels to ensure that consumers obtaining and light real-and and first alse support and service. The warranty on GTO products is NOT IVALDII of the products have been purchased from an unauthorized, on-line To Is-tailer (e.g., Is-bay® selfers what are not admirated GTO or Mighty Mulle resellent), or if a product's serial number has been altered, removed, or replaced in any way. To verify that you are buying from an authorized, on-line To Is-tailer (via I www. Gloresecs scon., or call 1400-543-4283.

In the case of product failure due to defective material or manufacturer workmanship within the one (1) year warranty prori, the open even till be reprised as (10 Access Systems, LLC, 231 Harstield Road, 11 Harstield Road, 18 AS 23303. IMPORTANT Call (800) 543-1236 or Tax (830) 575-5890 for a Betturn Goods Authorization (RGA) number before returning tenting to the cheevy without an RGA number will not be accepted. Replacement or repaired parts are convered by this warranty for the remainder of the one (1) year warranty period or six (6) months, whichever is greater. GTO will pay shipping costs (see Jacks and 10 Access 11 A

The manufacturer will not be responsible for any charges or damages incurred in the removal of the defective parts for repair, or the reinstallation of these parts after repair. Use of any components that are not GTO s transformery will void the warranty. This warranty shall be considered void if damage to the product(s) was due to improper installation or use, use of non-GTO specified or approved components or replacement parts, copover source, or if change was caused by lightimg, electrical power sugge, wind fire, flood, insector, or does natural agents.

This warranty gives you specific legal rights, and you may also have other rights which may vary from state to state. This warranty is in lieu of all other warranties, either expressed or implied.

After the one (1) year warranty period expires, GTO (or one of its authorized service centers) will perform necessary repairs for a nominal fee. Call GTO Technical Service at 800-543-1236 for more information