




## Measure Exact Opening Size



**Swinging Doors**



**Sliding Bath Doors**



**Sliding Shower Doors**

1. Measure the width of the shower door opening **A** and **B**. If the difference between **A** and **B** is less than  $\frac{3}{4}$  inch, this shower door will work for you.
2. Measure the height of the shower door opening **C** from the threshold to the top of the alcove or tile. Subtract 3 inches from measurement **C**. That is your maximum door height.
3. Confirm that the flat surface of the threshold is at least  $2\frac{1}{2}$  inches or greater and the wall has 3 inches or greater of flat surface for proper installation.



THE BOLD LOOK  
OF **KOHLER**.