



LINE BBQ LINE

MODEL KDF6016


SHEET 1 OF 7




TOP VIEW



ISOMETRIC VIEW



FRONT VIEW



SIDE VIEW

UNLESS OTHERWISE SPECIFIED:

- 1)-Add 1 1/2" to all base sides for rock finishes
- 2)-6" Max. height on all stubs-ups
- 3)-Keep gas & water lines to the far left or right to prevent fitting issues
- 4)-Subtract 3 1/2" from inner perimeter
- 5)-Product specifications are subject to change without notice
- 6)-Equipment Placement in this drawing is standardized and cannot be customize



PROPRIETARY AND CONFIDENTIAL
 THE INFORMATION CONTAINED IN THIS
 DRAWING IS THE SOLE PROPERTY OF
 CAL FLAME ANY REPRODUCTION
 IN PART OR AS A WHOLE WITHOUT
 THE WRITTEN PERMISSION
 OF CAL FLAME IS PROHIBITED.

TITLE: **2013 BBQ LINE
 KD FRAME
 KDF6016**

SIZE A	DWG NO.	REV
SCALE 1:16	DWG BY S. Linares	DATE 07/23/13


KD FRAME CHECKLIST 6016

LINE	BBQ LINE
MODEL	KDF6016
SHEET 2 OF 7	



**BACK FRAME
[1 PC.]**


**TOP FRAME
[1 PC.]**




**BASE LIFT SUPPORT
[3 PCS.]**




**FRONT FRAME
[1 PC.]**



**BAR FRAME
[1 PC.]**



**SIDE FRAME
[2 PCS.]**



**#1 SELF TAPPING
SCREW
[30 PCS.]**



UNLESS OTHERWISE SPECIFIED:

- 1)-Add 1 1/2" to all base sides for rock finishes
- 2)-6" Max. height on all stubs-ups
- 3)-Keep gas & water lines to the far left or right to prevent fitting issues
- 4)-Subtract 3 1/2" from inner perimeter
- 5)-Product specifications are subject to change without notice
- 6)-Equipment Placement in this drawing is standardized and cannot be customize



PROPRIETARY AND CONFIDENTIAL
THE INFORMATION CONTAINED IN THIS
DRAWING IS THE SOLE PROPERTY OF
CAL FLAME ANY REPRODUCTION
IN PART OR AS A WHOLE WITHOUT
THE WRITTEN PERMISSION
OF CAL FLAME IS PROHIBITED.




**TITLE: 2013 BBQ LINE
KDF6016
CHECK LIST**

SIZE A	DWG NO.	REV
SCALE 1:16	DWG BY S. Linares	DATE 07/12/13

STEP#1

LINE	BBQ LINE
MODEL	KD FRAME ASSEM.
SHEET 3 OF 7	

- **FIRST, ALIGN BACK AND SIDE FRAME TOGETHER AS SHOWN IN DIAGRAM (NOTE: THE USE OF A SET OF CLAMPS WILL FACILITATE THE JOB, AND GET A PERFECT ALIGNMENT)**
- **NEXT, SCREW IN BOTH FRAMES AS SHOWN IN DETAIL B; USING PROVIDED #10 SCREWS.**
- **FINALLY, REPEAT PROCESS FOR BOTH SIDES.**



DETAIL A
SCALE 1 : 4

UNLESS OTHERWISE SPECIFIED:

- 1)-Add 1 1/2" to all base sides for rock finishes
- 2)-6" Max. height on all stubs-ups
- 3)-Keep gas & water lines to the far left or right to prevent fitting issues
- 4)-Subtract 3 1/2" from iner perimeter
- 5)-Product specifications are subject to change without notice
- 6)-Equipment Placement in this drawing is standardized and cannot be customize



PROPRIETARY AND CONFIDENTIAL
THE INFORMATION CONTAINED IN THIS
DRAWING IS THE SOLE PROPERTY OF
CAL FLAME ANY REPRODUCTION
IN PART OR AS A WHOLE WITHOUT
THE WRITTEN PERMISSION
OF CAL FLAME IS PROHIBITED.

TITLE:
**2013 KD FRAME
ASSEM INSTRUCTIONS
KDF6016**

SIZE A	DWG NO.	REV
SCALE 1:16	DWG BY S. Linares	DATE 07/12/13


STEP#2

LINE	BBQ LINE
MODEL	KD FRAME ASSEM.
SHEET 4 OF 7	


• FIRST, ALIGN PREVIOUS ASSEMBLED FRAME FROM STEP #1 WITH FRONT FRAME AS SHOW IN DIAGRAM

(NOTE: THE USE OF A SET OF CLAMPS WILL FACILITATE THE JOB, AND GET A PERFECT ALIGNMENT)

• FINALLY, SCREW IN BOTH FRAMES AS SHOWN IN BELOW DIAGRAM; USING PROVIDED #10 SCREWS.



FRONT FRAME
SIDE



UNLESS OTHERWISE SPECIFIED:

- 1)-Add 1 1/2" to all base sides for rock finishes
- 2)-6" Max. height on all stubs-ups
- 3)-Keep gas & water lines to the far left or right to prevent fitting issues
- 4)-Subtract 3 1/2" from inner perimeter
- 5)-Product specifications are subject to change without notice
- 6)-Equipment Placement in this drawing is standardized and cannot be customize



PROPRIETARY AND CONFIDENTIAL
THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF CAL FLAME ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF CAL FLAME IS PROHIBITED.

TITLE: **2013 KD FRAME ASSEM INSTRUCTIONS KDF6016**

SIZE A	DWG NO.	REV
SCALE 1:16	DWG BY S. Linares	DATE 07/12/13


STEP#3

LINE	BBQ LINE
MODEL	KD FRAME ASSEM.
SHEET 5 OF 7	


- FIRST, ALIGN PREVIOUS ASSEMBLED FRAME FROM STEP #2 WITH TOP FRAME AS SHOW IN DIAGRAM

(NOTE: THE USE OF A SET OF CLAMPS WILL FACILITATE THE JOB, AND GET A PERFECT ALIGNMENT)


- FINALLY, SCREW IN BOTH FRAMES AS SHOWN IN BELOW DIAGRAM; USING PROVIDED #10 SCREWS.



FRONT FRAME SIDE




SCREW LOCATION DIAGRAM
8 TOTAL PER SIDE



UNLESS OTHERWISE SPECIFIED:


- 1)-Add 1 1/2" to all base sides for rock finishes
- 2)-6" Max. height on all stubs-ups
- 3)-Keep gas & water lines to the far left or right to prevent fitting issues
- 4)-Subtract 3 1/2" from inner perimeter
- 5)-Product specifications are subject to change without notice
- 6)-Equipment Placement in this drawing is standardized and cannot be customize

	TITLE: 2013 KD FRAME ASSEM INSTRUCTIONS KDF6016		
	<small>PROPRIETARY AND CONFIDENTIAL</small> <small>THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF CAL FLAME ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF CAL FLAME IS PROHIBITED.</small>	<small>SIZE</small> A	<small>DWG NO.</small>
<small>SCALE</small> 1:16	<small>DWG BY</small> S. Linares	<small>DATE</small> 07/12/13	


STEP#4

- **FIRST, LIFT FRAME (MAY NEED THE HELP OF OTHER PERSON) AND SCREW IN PROVIDED BASE SUPPORTS USING #10 SCREWS AS SHOWN IN BELOW DIAGRAM.**
- **FINALLY, REPEAT PREVIOUS STEP TO COMPLETE ALL 3 SUPPORTS.**
NOTE: ALIGN PRE-DRILL HOLE TOGETHER FOR EASY INSTALLATION

LINE	BBQ LINE
MODEL	KD FRAME ASSEM.
SHEET 6 OF 7	



**SCREW LOCATION DIAGRAM
2 TOTAL PER SUPPORT**



DETAIL AA
SCALE 1 : 2

DETAIL Y
SCALE 1 : 2

BASE SUPPORT

UNLESS OTHERWISE SPECIFIED:

- 1)-Add 1 1/2" to all base sides for rock finishes
- 2)-6" Max. height on all stubs-ups
- 3)-Keep gas & water lines to the far left or right to prevent fitting issues
- 4)-Subtract 3 1/2" from inner perimeter
- 5)-Product specifications are subject to change without notice
- 6)-Equipment Placement in this drawing is standardized and cannot be customize



PROPRIETARY AND CONFIDENTIAL
 THE INFORMATION CONTAINED IN THIS
 DRAWING IS THE SOLE PROPERTY OF
 CAL FLAME ANY REPRODUCTION
 IN PART OR AS A WHOLE WITHOUT
 THE WRITTEN PERMISSION
 OF CAL FLAME IS PROHIBITED.


**TITLE: 2013 KD FRAME
 ASSEM INSTRUCTIONS
 KDF6016**

SIZE A	DWG NO.	REV
SCALE 1:16	DWG BY S. Linares	DATE 07/12/13


STEP#5 (KD6016)

- **FIRST, PLACE BAR FRAME ON TOP OF PREVIOUS ASSEMBLED FRAME.**
 - **NEXT, SCREW BOTH FRAME USING PROVIDED # 10 SCREWS. NOTICE TOP AND BOTTOM SCREW POINTS.**
- (NOTE: THE USE OF A SET OF CLAMPS WILL FACILITATE THE JOB, AND GET A PERFECT ALIGNMENT)**


LINE	BBQ LINE
MODEL	KD FRAME ASSEM.
SHEET 7 OF 7	



**SCREW LOCATION DIAGRAM
3 TOTAL**




**SCREW LOCATION DIAGRAM
6 TOTAL**



UNLESS OTHERWISE SPECIFIED:

- 1)-Add 1 1/2" to all base sides for rock finishes
- 2)-6" Max. height on all stubs-ups
- 3)-Keep gas & water lines to the far left or right to prevent fitting issues
- 4)-Subtract 3 1/2" from inner perimeter
- 5)-Product specifications are subject to change without notice
- 6)-Equipment Placement in this drawing is standardized and cannot be customize

	TITLE: 2013 KD FRAME ASSEM INSTRUCTIONS KDF6016		
	PROPRIETARY AND CONFIDENTIAL THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF CAL FLAME ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF CAL FLAME IS PROHIBITED.	SIZE A	DWG NO.
SCALE 1:16	DWG BY S. Linares		DATE 07/12/13