

## Wireless Rain Station




Instruction Manual  
Model: 724-1409  
DC: 081617

### STEP 1: POWER UP

Install batteries into your sensor & display.

**Note:** For detailed instructions on how to power up your station & sensor, please review the full manual. [www.lacrossetechnology.com/7241409](http://www.lacrossetechnology.com/7241409)



### STEP 2: MOUNT SENSOR

Mount in an open area, preferably level and off the ground. Center the bubble level inside the sensor for the most accurate rain readings. Clean out the bucket regularly to avoid debris build-up; this can affect readings.

### STEP 3: SETTINGS

Hold the HISTORY/TIME SET button to enter set mode. Use +/- buttons to adjust and SET to confirm.

#### SETTING ORDER

- |               |              |
|---------------|--------------|
| 1. Beep       | 6. Month     |
| 2. Hours      | 7. Date      |
| 3. Minutes    | 8. Date mode |
| 4. 12/24 Hour | 9. in or mm  |
| 5. Year       | 10. °F or °C |

### OTHER BUTTON FUNCTIONS

- Press **+ / MODE**: Select Calendar or Indoor Temperature
- Press **RAIN / ALERT**: View NOW, ONE HOUR, 24HR, 7 DAYS, MONTH, YEAR, or TOTAL rainfall
- Hold **RAIN / ALERT**: Set 24 hour Rain Alert
- Press **HISTORY / TIME SET**: To view monthly rain history
- Hold **SENSOR**: Search for rain sensor.

## WE'RE HERE TO HELP!

FIND FULL MANUALS & SUPPORT  
[www.lacrossetechnology.com/724-1409](http://www.lacrossetechnology.com/724-1409)

## JOIN THE CONVERSATION

Ask questions, watch detailed setup videos, and provide feedback on our social media outlets!



## NEED MORE HELP?

If you require additional support, call our friendly customer support representatives based out of our office in La Crosse, Wisconsin.

**Phone:** 1.608.782.1610

Our knowledgeable customer support team is available Monday-Friday, 8am-6pm CST.

## STATION & SENSOR SPECS

### RAIN STATION (724-1409)

- **Indoor Temperature Range:** 32°F to 99°F (0°C to 37°C)
- **Power Requirements:** 2 "AA" Batteries (not included)

### RAIN SENSOR (TX14R)

- **Rainfall Range:** 0-393.6 in (0-9999mm)
- **Transmission Range:** 300 ft (91 m) open air RF 433MHz
- **Power Requirements:** 2 "AA" Batteries (not included)

## WARRANTY INFO

La Crosse Technology, Ltd. provides a **1-year limited time warranty** (from date of purchase) on this product relating to manufacturing defects in materials & workmanship.

### For Full Warranty Details, Visit:

[www.lacrossetechnology.com/support](http://www.lacrossetechnology.com/support)

## CARE + MAINTENANCE

Do not mix old and new batteries. Do not mix Alkaline, Lithium, standard, or rechargeable batteries. Always purchase the correct size and grade of battery most suitable for intended use; Clean the battery contacts and also those of the device prior to battery installation; Ensure the batteries are installed with correct polarity (+ and -); Remove batteries from equipment that will not to be used for an extended period.

## FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Increase separation between equipment & receiver.
- Consult the dealer or an experienced radio/TV technician for help.

This device must not be co-located or operating in conjunction with any other antenna or transmitter.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

### Caution!

The manufacturer is not responsible for any radio or TV interference caused by unauthorized changes or modifications to this equipment. Such changes or modifications could void the user authority to operate the equipment.

All rights reserved. This manual may not be reproduced in any form, even in part, or duplicated or processed using electronic, mechanical or chemical process without the written permission of the publisher.

This booklet may contain errors or misprints. The information it contains is regularly checked and corrections are included in subsequent editions. We disclaim any responsibility for any technical error or printing error, or their consequences. All trademarks and patents are recognized.