


THE QUICK BENCH

THE FOLD DOWN WORK STATION



INSTRUCTION MANUAL & ASSEMBLY INSTRUCTIONS

Thank you for choosing The Quick Bench. This product will be an integral part of your life with an array of applications in garages, laundry rooms, kitchens, and anywhere you need extra space.

FOR MORE INFO PLEASE VISIT WWW.MYQUICKBENCH.COM



WARNING



TO REDUCE THE RISK OF SEVERE INJURY OR DEATH:

- READ AND FOLLOW ALL DIRECTIONS
- Never apply more force than the products published load limit
- Do not make any modifications to the product
- Never operate unless bench is properly installed and secured to wood studs
- Never allow children to operate or play on or around bench
- Never operate bench under the influence of alcohol or drugs



THE QUICK BENCHS CAPACITY IS 500 LBS. OF STATIC LOAD EVENLY DISTRIBUTED OVER THE TOP OF THE BUTCHER BLOCK COUNTERTOP.

THE BRACKETS MUST BE ANCHORED TO 2" STUDS TO PERFORM CORRECTLY AND BE ABLE TO SUPPORT THE RATED CAPACITY.



THIS PRODUCT MUST BE SECURELY MOUNTED TO WOOD STUDS ON A FLAT WALL. THE WOOD STUDS MUST HAVE THE ABILITY TO HOLD THE WEIGHT OF THE QUICK BENCH AND ITS CONTENTS. ANY MISAPPLICATION OF THIS PRODUCT TO NON-STUDS WILL VOID THE WARRANTY AND THE PRODUCT WILL BE DEEMED UNSAFE DUE TO OWNER'S INSTALLATION ERROR.

If you do not feel comfortable installing this bench, contact a licensed professional.



ASSEMBLY TIME SHOULD TAKE AROUND 20-MINUTES WITH ONE PERSON TO ATTACH THE BRACKETS TO THE STUD WALL AND TWO PEOPLE TO LIFT THE BUTCHER BLOCK TOP AND FASTEN IT IN PLACE.

TOOLS & MATERIALS NEEDED

TOOLS (NOT INCLUDED)

- Drill
- 5/32" Drill Bit
- 10 mm Socket
- Stud Finder
- Tape Measure
- Level
- Pencil
- Square
- Phillips Screwdriver

HARDWARE (INCLUDED)


QTY	DESCRIPTION
1	Wood Top
2	Mounting Brackets
7	1" Screws
7	2 3/8" Lag Bolts
7	Washers

ASSEMBLY INSTRUCTIONS

STEP 1



- Determine and mark the desired height of the workbench on the wall with a pencil. (NOTE: The bench is designed to operate at a height of 30 inches to 72 inches.)
- Use a stud finder to find the closest stud and mark the location. Then measure 2 3/4" down from your predetermined workbench height and predrill a hole with the 5/32" bit.
- When hole is predrilled, fold down spring support plate and secure top bolt and washer using your 10 mm socket through bracket and into stud behind wall. Make sure support plate is all the way down so it does not create a pinch point.
- Measure 24" or 32" to the left or right from your first located stud and locate your other mounting position using the stud finder. (NOTE: Stud spacing in American Residential Settings is 16" or 24" on center and your New Quick Bench must be anchored to the center of the Studs.)
- Repeat the previous process and install the top bolt on the second mounting bracket.
- Use a level to make sure both brackets are level, and then pre drill the remaining holes on each bracket.
- Make sure all 6 anchor screws and washers are fastened securely into studs on the vertical walls before continuing.



STEP 2

- Lift the brackets into the UP position with the latches set at a right angle and the locking bracket LOCKED as seen below.
- Place the countertop on the brackets with the back edge securely against the stop tab on the bracket. (NOTE: This will leave a 1/4" space between the wood top and the wall.)
- Center wood top between the brackets. (NOTE: If the brackets are placed 16" apart, the ends of the bench will be 16" from the outside of the brackets. If the brackets are placed 24" apart, there will be 12" from the ends to the outside of the brackets.)
- Screw the 6 - 1" screws into the underside of the countertop to fasten the board in place. (NOTE: Have a second person hold the board in place to make sure it does not move or fall.)

OPERATING INSTRUCTIONS

PLEASE NOTE THAT BEFORE USING YOUR BENCH, IT IS IMPORTANT THAT YOU UNDERSTAND THAT AFTER THE ASSEMBLY IS COMPLETE, LOCATIONS IN AND AROUND YOUR HINGES WILL CREATE PINCH POINTS.



1. Ensure bench is clear of all items that could interfere with the bench's range of motion and that all bolts and screws are securely fastened to the studs and the countertop.
2. To raise the bench, lift the bench upward until you hear the brackets click and lock into place.
3. To lower the bench, stand in front of the bench and use your fingers to compress the release on the end of both brackets, and then lower the bench to the wall. When you lower the bench it will fit flush against the wall.