

- Carefully untie the string and remove the loose wood block and bag with (2) button head fasteners and a screw. (Set aside, as these items will be used in the last step.)
- Using a screw gun, install the 1st wood block (with the attached screw) at the height desired for your trellis. Make sure the (2) button head fasteners are against the structure. **Note: These screws do not require pre-drilling a hole.** (Always apply a caulking sealer on the screw point when installing on a building.)
- Unroll the mesh, remove the laced-in screw & the (2) button head fasteners from the 2nd wood block (careful, the buttons are meant to be removable and may fall out). Re-install the (2) button head fasteners through the mesh and into the back of the block at the desired trellis length. Partially install the long screw into the block making sure the (2) button head fasteners are against the structure.
- Pull the 2nd block until mesh is straight, then with a screw gun, start the screw on slight angle until screw starts to bite.
- With the screw partially installed, rotate block so the mesh is tight, then completely drive screw in tight.
- Trim any excess loose mesh with household scissors.
- Mount the "Mid" Support Block to the mesh with the (2) button head fasteners then use the screw gun to secure Block to structure. Note: the (2) button head fasteners should be against the structure.

