




#1
The wood post repair
solution on the market.

Anatomy of The Post Doctor

Wood Screw Holes
(Are All Lower Holes)

The Post Doctor is Paintable
Hammer Edge



What comes in the kit

Included:
1-Post Doctor
1-11" x 5/16" drill bit
1-Phillips head bit
1- 5" Through bolt
2-Washers
2-Lock Washers
3-Wood screws
1-Lock Nut

Tools Needed:
Hammer
Drill
Crescent Wrench
7/16" Socket head wrench
1" x 6' wood brace

Instructions:

1- Level the post with braces to the front and side




2- Dig down to the top of the cement surface, and clear away as much dirt as possible, preferably at least two inches around the entire circumference of the existing cement foundation



3- Pull The Post Doctor from the packaging and remove the green protective tip coating. Push the post doctor flush to the outside walls of the post. Gently hammer it in place, if necessary tap the bottom of all three spikes so that they can make easy penetration into the wood below the cement surface.

Remove protective
coating from the 3
points of The
Post Doctor



4- Hold The Post Doctor against post and begin hammering on upper middle edge and alternating between all upper edges until The Post Doctor goes down into the below grade timber evenly and comes to rest flush on concrete



5- Screw The Post Doctor to post on all 3 sides with provided wood screws



6- First drill a 2" starter hole from the right side of The Post Doctor through the 3/8" opening. Then drill hole through post from left side using supplied 5/16" wood boring bit, drilling through the 3/8" opening on the right side of The Post Doctor where you drilled the 2" starter hole.



7- Place supplied hex head bolt with washer through drilled hole tap through. Place washer and nut at other end and tighten



8- Mix concrete and pour around base of The Post Doctor, fill any cracks, finish smooth



9- Wait for concrete to dry and remove post supports

Job Complete

