

STEEL WINDOW WELL

INSTALLATION INSTRUCTIONS

PREPARATION

Review local building codes to ensure compliance.

Contact Diggers hotline prior to excavating.

Ensure faucets, downspouts, sprinklers, and hoses are at least 10' from the well and are aimed away from the well.

Excavate a hole that is 12" wider than the well in all directions and 10" below the bottom edge of the window.

INSTALLATION

1. Mark the location of the top mounting holes on the foundation.

- For 50" width model, holes should be 52" apart center to center.

- For 68" width model, holes should be placed 70" apart center to center.

2. Drill two hole on the markings and remove all concrete dust from the holes before proceeding.

3. Place your hardware in the hole and place well on the anchor. Add a 1" flat washer and nut and tighten into place.

4. Using the remaining holes on the window well flange, drill the remaining holes.

5. Place remaining hardware into the holes, add 1" flat washers and nuts and tighten into place.

6. Using hand tools only, backfill around the well in 6-8" layers. Each layer should be packed down to ensure proper support of the steps.

Mounting
Hole

