

# OWNER'S MANUAL FLYING INSECT ELIMINATOR

**MODEL: DT2000XLGR** 

Thank you for purchasing the DYNATRAP®XL flying insect trap!

Please read and understand these instructions thoroughly for correct usage and keep it in a safe place for future reference.

## LIMITED WARRANTY

DYNAMIC SOLUTIONS WORLDWIDE, LLC warranties to the original purchaser that this product is free from defective materials and workmanship. This warranty is limited to remedy any defective part for a period of one year from date of original date of purchase. Retain your original receipt as proof of purchase. This warranty does not apply to the light bulb, nor to, in our judgment, misuse or abuse. If this unit has been altered, no warranty is in force. This warranty does not apply if this unit is purchased outside the United States, excluding Canada and Mexico. In no case shall DYNAMIC SOLUTIONS WORLDWIDE, LLC be liable for any accidental, punitive, consequential, or any other damages of any kind for breach of this or any other warranty, expressed or implied, whatsoever. Some states do not allow limitation on how long an implied warranty lasts, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state.

# **PARTS & ACCESSORIES**

# PART DESCRIPTION

32050 6-Watt Replacement Fluorescent Bulb (2 pieces)

# **ODYNAMIC.**

Dynamic Solutions Worldwide, LLC 12247 Fairview Ave. Milwaukee, WI 53226 Phone: 414-431-2819 Fax: 414-453-9975

Or visit us online at www.dynatrap.com EPA Est. No. 087837-WI-001 EPA Est. No. 086034-CHN-001 ©2010 Dynamic Solutions Worldwide, LLC

## **IMPORTANT SAFETY INSTRUCTIONS**

Please read these instructions before using the DYNATRAP®XL Insect Eliminator and keep for future reference.

- 1. Always turn unit off and disconnect plug before servicing, cleaning, or changing bulbs.
- 2. Do not mount the unit near heat, gas, oil or other flammable materials.
- Mount product out of reach from children.
- Never operate this product if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or if it has been dropped into water.
- 5. This product is equipped with 2-conductor cord and 2-prong polarized plug as a safety feature. This plug will fit in a polarized outlet only one way. If the plug does not fully fit in the outlet, then reverse the plug. If it still does not fit, then contact a qualified electrician. To reduce the risk of electrical shock, only plug into a properly installed outlet. Do not attempt to defeat this safety feature.
- 6. Do not insert fingers or any foreign objects into the unit while it is connected to an electrical outlet.
- 7. Collected insects within the unit may contribute to fire, so clean insects from the unit frequently.
- 8. Do not clean this product with water spray. Do not place where it can fall into water, or near flammable materials.
- Do not touch fan while in motic
- Do not abuse cord—never carry or hang unit by cord or yank it to disconnect from receptacle. Keep cord away from heat, oil, or sharp edges.
- 11. Extension cords used with this product must be marked with suffix letters "W-A" and with a tag stating "Suitable for Use with Outdoor Appliances".
- 12. Use only extension cords that have plug and receptacles that match the product plug. Replace or repair damaged cords.

## HOW THE DYNATRAP®XL INSECT ELIMINATOR WORKS

Flying insects are attracted to the unit by the light along with the  ${\rm CO}_2$  that is generated by the photo-catalysis between the UV lamps and the  ${\rm TiO}_2$  coat, and then the fan pulls the insects into the net, trapping them until they dehydrate and die. The screened base can be removed, so you can periodically empty the contents into the trash. The screen allows you to see what's trapped in the compartment, alerting you when the net needs to be emptied.



#### INSTALLATION

- 1. Unpack unit. Save carton for off-season storage.
- If hanging or mounting the unit place approximately 5-6 feet above floor/ground level for optimal catch rate and easy access for cleaning.
- 3. Plug cord into an outdoor outlet or UL listed extension cord as described in "IMPORTANT SAFETY INSTRUCTIONS".
- 4. For best catch results leave unit on at all times, except when cleaning or servicing.
- Catch rate activity will be higher at night. For best catch results it is recommended to place unit away from other competing light sources.

#### **CLEANING**

Frequent cleaning will prolong the life of the unit, insure fire prevention and provide for more efficient operation.

- Be sure to clean the unit at least once a week.
- 2. Switch the unit off and unplug before cleaning.
- 3. For weekly cleaning, remove the net and clear any build up from the inside of the trap with a brush.

#### **REPLACING BULBS**

Light bulbs life expectancy is approximately 5,000 hours (or about 6 months), and should be replaced after that time has passed in order to maintain optimal UV effectiveness. Even though the bulb's light may be visible to you, it's ability to aftract insects diminishes over time.

- 1. Turn power switch 10 "off" position, UNPLUG UNIT, and allow bulbs to cool before replacing.
- 2. Carefully turn bulb counterclockwise and then pull bulb straight out.
- Locate and inset the new bulbs into sockets, carefully turn clockwise, and make sure the prongs of the bulb are sented properly.

Replacement Bulbs (6-Wall fluorescent bulbs) can be found of your local retailer or can be ordered directly from DYNAMIC SOLUTIONS WORLDWIDE, LLC. by calling 1-877-403-Trap(8727).

#### **TROUBLESHOOTING**

Problem	Possible cause:	Correction:
Bulbs do not illuminate and fan does not spin.	1. No electrical power.	Check plug and receptacle and fuse or circuit breaker.     Check to make sure power is switched to the "on" position.
Bulbs illuminate, but fan does not spin.	1. Shorted fan.	UNPLUG UNIT: Examine fan to see that it is free from foreign material, dirt or build-up of dead insects. Clean unit as in "CLEANING" section.
Fan spins, but bulbs do not illuminate.	Bulb not seated properly.     Burnt out bulb.	Check all sockets for proper bulb seating and alignment.     Replace bulb if needed following instructions under "Replacing Bulbs".